

# NB LINEAR SYSTEM

The NB linear system is a linear motion mechanism which utilizes the rolling motion of ball and/or roller elements. NB offers a wide range of linear motion products of high precision quality that contribute to the size and weight reduction of machinery and equipment.


## ADVANTAGES

### Low Friction and Excellent Response

The dynamic friction of the ball or roller elements is substantially lower than that of full-face surface sliding friction. Since the difference between dynamic and static frictional resistance is small, motion response is excellent in terms of positioning accuracy and in high speed applications with acceleration and deceleration.

### High Precision and Smooth Movement

The NB linear system is designed for the rolling elements to achieve extremely smooth motion. The raceway surface is finished by precision grinding for high precision movement with optimal clearance.



### High Load Capacity and Long Travel Life

Despite the compactness of the NB linear system, the system uses relatively large rolling elements on a long raceway resulting in a high load capacity and a long travel life.


### Ease of Installation

The NB linear system shortens machining and assembly time compared with that of a full-face surface sliding bearing.

### Variety of Types

A wide variety of types and sizes of the NB linear systems are available to best serve the purpose for every application and requirement.

## PROCESS FOR SELECTING NB LINEAR SYSTEM



## ALLOWABLE LOAD

### Load and Moment

A load is applied to the linear system as Figure 1-1 shows. Sometimes moment loads are applied to, for example, slide guides. Load and moment are defined as follows.

### Basic Static Load Rating (compliant with ISO14728-2<sup>\*1</sup>) and Allowable Static Moment

When excess load or impact load is applied to the linear system while it is stationary or moving slowly, a permanent deformation occurs on the rolling elements and the race way.

If this deformation exceeds a certain limit, it causes vibration and noise during operation resulting in a non-smooth motion and a shorter life time. To prevent this permanent deformation and deterioration in motion accuracy, the basic static load rating ( $C_0$ ) is given as the allowable load for the linear system. This basic static load rating is defined as the static load that results in the maximum allowable stress at the center of the contact surface between the rolling elements and the race way. The sum of the permanent deformation of the rolling element and that of the race way is 0.0001 times the diameter of the rolling element. In the linear system, a moment load may be present in addition to the static load. The allowable static moments are defined by  $M_p$ ,  $M_y$ , and  $M_r$  as illustrated in Figure 1-1.

\*1: This does not apply to some products.

### Allowable Load and Static Safety Factor

The basic static load rating and allowable static moment define the maximum static load in each direction, however, these maximum static loads are not necessarily applicable depending on the operating conditions, the mounting accuracy, and the required motion accuracy. Therefore, an allowable load with a safety factor must be obtained. The minimum static safety factor is listed in Table 1-1.

#### Allowable Load

$$P_{max} \leq C_0 / fs \quad \dots \dots \dots (1)$$

#### Allowable Moment

$$M_{max} \leq (M_p, M_y, M_r, M_{p2}, M_{y2}) / fs \quad \dots \dots \dots (2)$$

$fs$ : static safety factor    $C_0$ : basic static load rating (N)

$P_{max}$ : allowable load (N)


$M_p, M_r, M_y, M_{p2}, M_{y2}$ : allowable static moment (N · m)

$M_{max}$ : allowable moment (N · m)

Table 1-1 Minimum Static Safety Factor (fs)

| operating conditions     | static safety factor |
|--------------------------|----------------------|
| normal                   | 1~2                  |
| smooth motion required   | 2~4                  |
| vibration/impact loading | 3~5                  |

Figure 1-1 Load and Moment



## LIFE

### Life of a Linear System

When a linear system reciprocates under loading, a continuous stress acts on it, ultimately causing flaking of its race way surface due to material fatigue. The distance a linear system travels before this flaking occurs is defined as the life of the linear system. A linear system can also become inoperable due to sintering, cracking, pitting, or rusting, however, these causes are differentiated from flaking because they are related to installation accuracy, operating environment, and relubrication method.

### Rated Life

Even when a group of linear systems from the same production lot operated under identical conditions, the life time can differ due to differences in the material fatigue failure characteristics. This fact prevents from determining the exact life time of a single linear system for use. Therefore, the rated life is defined statistically as the distance of 90% of the linear systems travel before causing flaking.

### Basic Dynamic Load Rating (compliant with ISO14728-1<sup>\*2</sup>) and Basic Dynamic Torque Rating

The life of a linear system is expressed in terms of the distance traveled. Therefore, the life of a linear system is calculated reversely by using the allowable load that achieves a certain travel distance. This allowable load is called the basic dynamic load rating. The basic dynamic load rating is defined as a constant load in weight and direction that can achieve a travel distance of  $50 \times 10^3$ m on the linear system. NB assumes the load is applied from the top as a normal radial load, because basic dynamic load ratings change depending on the applied load direction. The basic dynamic load ratings in the dimensional tables are based on this assumption. Ball splines can carry torque loading, so the basic dynamic torque rating is defined for the Ball Spline.

\*2: This does not apply to some products.

### Rated Life Estimation

The rated life estimation depends on the type of the rolling element. Equations (3) and (4) are used for the ball element and for the roller element, respectively. Equation (5) is used when torque loading is present.

balls are used as the rolling element

$$L = \left( \frac{C}{P} \right)^3 \cdot 50 \quad \dots \dots \dots (3)$$

rollers are used as the rolling element

$$L = \left( \frac{C}{P} \right)^{10/3} \cdot 50 \quad \dots \dots \dots (4)$$

torque loading is present

$$L = \left( \frac{C_T}{T} \right)^3 \cdot 50 \quad \dots \dots \dots (5)$$

L: rated life (km)   C: basic dynamic load rating (N)

P: applied load (N)   C<sub>T</sub>: basic dynamic torque rating (N · m)

T: applied torque (N · m)

In the actual application, numerous variable factors are present such as in guide rail/shaft accuracy, in mounting conditions, in operating conditions, vibration and shock, etc. Therefore, calculating the actual applied load accurately is extremely difficult. In general, the calculation is simplified by using coefficients representing these factors: hardness coefficient ( $f_H$ ), temperature coefficient ( $f_T$ ), contact coefficient ( $f_C$ ), and applied load coefficient ( $f_w$ ). Taking these coefficients into account, Equations (3) to (5) become Equations (6) to (8).

balls are used as the rolling element

$$L = \left( \frac{f_H \cdot f_T \cdot f_C \cdot C}{f_w P} \right)^3 \cdot 50 \quad \dots \dots \dots (6)$$

rollers are used as the rolling element

$$L = \left( \frac{f_H \cdot f_T \cdot f_C \cdot C}{f_w P} \right)^{10/3} \cdot 50 \quad \dots \dots \dots (7)$$

torque loading is present

$$L = \left( \frac{f_H \cdot f_T \cdot f_C \cdot C_T}{f_w T} \right)^3 \cdot 50 \quad \dots \dots \dots (8)$$

L: rated life (km)   f<sub>H</sub>: hardness coefficient

f<sub>T</sub>: temperature coefficient   f<sub>C</sub>: contact coefficient

f<sub>w</sub>: applied load coefficient   P: applied load (N)

C: basic dynamic load rating (N)

C<sub>T</sub>: basic dynamic torque rating (N · m)

T: applied torque (N · m)

When the travel distance per unit time is constant, the rated life can be expressed in terms of time (hour). Equation (9) shows the relationship between stroke length, number of cycles per minute, and the life time.

#### • Hardness Coefficient ( $f_H$ )

In the linear system, the guide rail or shaft works as race way of the rolling elements. Therefore, the hardness of the rail or shaft is an important factor in determining the rated load. The rated load decreases as the hardness decrease below 58HRC. NB products hold appropriate hardness by advanced heat treatment technology. In case of using the rail or shaft of insufficient hardness, please take the hardness coefficient (Figure 1-2) into the life calculation equation.

#### • Temperature Coefficient ( $f_T$ )

In order to give low wear characteristics NB products are hardened by heat treatment. If the temperature of the linear system exceeds 100°C, the hardness is decreased by tempering effect, so as the rated load decreases. Figure 1-3 shows the temperature coefficient as hardness changes with temperature.

#### • Contact Coefficient ( $f_c$ )

When more than one bearing is used in close contact, the contact coefficient should be taken into consideration due to the variation of products and the accuracy of the mounting surface. Table 1-2 shows the contact coefficient for life calculation.

#### • Applied Load Coefficient ( $f_w$ )

The actual applied load on a liner system can be greater than the calculated load due to impact, vibration, or inertia. Hence, an appropriate applied load coefficient(table 1-3) must be incorporated into a life calculation.

There are separate applied load coefficient tables for TOPBALL products on page D-4.

$$L_h = \frac{L \cdot 10^3}{2 \cdot \ell_s \cdot n_1 \cdot 60} \dots \quad (9)$$

$L_h$ : life time (hr)     $l_s$ : stroke length (m)  
 $n_1$ : number of cycles per minute (cpm)

Figure 1-2 Hardness Coefficient



Figure 1-3 Temperature Coefficient




Table 1-2 Contact Coefficient

| number of linear bearings in close contact on rail/shaft | contact coefficient $f_c$ |
|--|---------------------------|
| 1  | 1.00                      |
| 2  | 0.81                      |
| 3  | 0.72                      |
| 4  | 0.66                      |
| 5  | 0.61                      |

Table 1-3 Applied Load Coefficients

| operating conditions     |               | applied load coefficient |
|--------------------------|---------------|--------------------------|
| loading                  | velocity      | $f_w$                    |
| no shock and vibration   | 0.25 m/s less | 1.0~1.5                  |
| low shock and vibration  | 1 m/s less    | 1.5~2.0                  |
| high shock and vibration | 1 m/s more    | 2.0~3.5                  |

## Calculation of Applied Load (1)

Tables 1-4 and 1-5 show the formulas of applied load calculation for typical applications.

W: applied load (N) P<sub>1</sub> - P<sub>2</sub>: load applied to linear system (N) X,Y: linear system span (mm)  
 x, y,  $\ell$ : distance to applied load or to working center of gravity (mm) g: gravitational acceleration ( $9.8 \times 10^3 \text{ mm/s}^2$ )  
 V: velocity (mm/s) t<sub>a</sub>: acceleration time (sec) t<sub>d</sub>: deceleration time (sec)

Table 1-4 Applied Load Calculation (1)










| condition  | applied load calculation formula  |
|--|---|
| under static conditions or constant velocity motion<br>2 horizontal axes | <br>  |
| 2 horizontal axes,<br>over-hang  | <br>  |
| 2 horizontal axes,<br>moving axes  | <br> <p>Note : If the calculation results in a negative value, the loading direction is in the opposite direction.</p> |

Table 1-5 Applied Load Calculation (2)

|   | condition  | applied load calculation formula   |
|---|--|--|
| under static conditions or constant velocity motion | 2 horizontal, side axes<br>   | $P_1 = P_2 = P_3 = P_4 = \frac{\ell_1}{2Y}W$<br>$P_{1s} = P_{3s} = \frac{1}{4}W + \frac{x_0}{2X}W$<br>$P_{2s} = P_{4s} = \frac{1}{4}W - \frac{x_0}{2X}W$ |
| under static conditions or constant velocity motion | 2 vertical axes<br>   | $P_1 = P_2 = P_3 = P_4 = \frac{\ell_1}{2X}W$<br>$P_{1s} = P_{2s} = P_{3s} = P_{4s} = \frac{\ell_2}{2X}W$   |
| under constant acceleration conditions              | 2 horizontal axes<br><br>velocity diagram<br>$V_1 \text{ (mm/sec)}$<br>$t_1, t_2, t_3 \text{ (sec)}$<br>under acceleration<br>$P_1 = P_3 = \frac{1}{4}W \left(1 + \frac{2V_1\ell_1}{gt_1X}\right)$<br>$P_2 = P_4 = \frac{1}{4}W \left(1 - \frac{2V_1\ell_1}{gt_1X}\right)$<br>under deceleration<br>$P_1 = P_3 = \frac{1}{4}W \left(1 - \frac{2V_1\ell_1}{gt_3X}\right)$<br>$P_2 = P_4 = \frac{1}{4}W \left(1 + \frac{2V_1\ell_1}{gt_3X}\right)$<br>under constant velocity<br>$P_1 = P_2 = P_3 = P_4 = \frac{1}{4}W$<br>※g: acceleration of gravity<br>( $9.8 \times 10^3 \text{ mm/sec}^2$ ) |  |

### • Equivalent Coefficient

The linear systems are generally used with two axes, each axis with a couple of bearings installed. However, due to a space limitation, there must be an application in which one axis with one or two bearings in close contact installed. In such a case, multiply the applied moment by the equivalent moment coefficient shown in Tables 1-7~1-25 for applied load calculation. The following is a formula for calculating the equivalent moment load when a moment is applied to the linear system.

$$P = E \cdot M$$

P: equivalent moment load per bearing (N)  
E: equivalent moment coefficient  
M: applied moment (N · mm)

### Calculation of Applied Load (2)

Table 1-6 shows the formulas for determining the applied load when moment is applied to the linear system.

W: applied load (N) P: load applied to the linear system (N) ℓ: distance to applied load or to working center of gravity (mm)

Table 1-6 Applied Load Calculation (3)






|                    | condition   | applied load calculation formula  |
|--------------------|---|---|
| 1 axis application | 1 horizontal axis,<br>1 bearing<br>      | $P = W + E_{P1}W\ell_1 + E_RW\ell_2$<br>E <sub>P1</sub> : Mp equivalent coefficient with 1 bearing used<br>E <sub>R</sub> : Mr equivalent coefficient                         |
| 1 axis application | 1 sideway axis,<br>1 bearing<br>         | $P = W + E_{Y1}W\ell_1 + E_RW\ell_2$<br>E <sub>Y1</sub> : My equivalent coefficient with 1 bearing used<br>E <sub>R</sub> : Mr equivalent coefficient                         |
| 1 axis application | 1 vertical axis,<br>1 bearing<br>        | $P = E_{P1}W\ell_1 + E_{Y1}W\ell_2$<br>E <sub>P1</sub> : Mp equivalent coefficient with 1 bearing used<br>E <sub>Y1</sub> : My equivalent coefficient with 1 bearing used     |
| 2 axes application | 2 horizontal axes,<br>1 bearing each<br> | $P = W/2 + W\ell_2/Y + E_{P1}W\ell_1/2$<br>E <sub>P1</sub> : Mp equivalent coefficient with 1 bearing used<br>Y: span between the two axes centers                            |
| 2 axes application | 2 sideway axes,<br>1 bearing each<br>  | $P = W/2 + E_{Y1}W\ell_2/2 + W\ell_1/Y$<br>E <sub>Y1</sub> : My equivalent coefficient with 1 bearing used<br>Y: span between the two axes centers                            |
| 2 axes application | 2 vertical axes,<br>1 bearing each<br> | $P = E_{P1}W\ell_1/2 + E_{Y1}W\ell_2/2$<br>E <sub>P1</sub> : Mp equivalent coefficient with 1 bearing used<br>E <sub>Y1</sub> : My equivalent coefficient with 1 bearing used |

Table 1-7 Slide Guide SEB type

| part number        | equivalent coefficient |                       |                       |                       |                       | unit : 1/mm |
|--------------------|------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-------------|
|                    | E <sub>P1</sub>        | E <sub>P2</sub>       | E <sub>Y1</sub>       | E <sub>Y2</sub>       | E <sub>R</sub>        |             |
| <b>SEBS 5B</b>     | $6.64 \times 10^{-1}$  | $9.61 \times 10^{-2}$ | $7.91 \times 10^{-1}$ | $1.15 \times 10^{-1}$ | $3.85 \times 10^{-1}$ |             |
| <b>SEBS 5BY(D)</b> | $5.17 \times 10^{-1}$  | $8.38 \times 10^{-2}$ | $6.16 \times 10^{-1}$ | $9.99 \times 10^{-2}$ | $3.85 \times 10^{-1}$ |             |
| <b>SEBS 7BS</b>    | $6.70 \times 10^{-1}$  | $7.76 \times 10^{-2}$ | $7.98 \times 10^{-1}$ | $9.25 \times 10^{-2}$ | $2.74 \times 10^{-1}$ |             |
| <b>SEBS 7B</b>     | $4.62 \times 10^{-1}$  | $6.65 \times 10^{-2}$ | $5.50 \times 10^{-1}$ | $7.93 \times 10^{-2}$ | $2.74 \times 10^{-1}$ |             |
| <b>SEBS 7BY</b>    | $2.84 \times 10^{-1}$  | $5.00 \times 10^{-2}$ | $3.38 \times 10^{-1}$ | $5.96 \times 10^{-2}$ | $2.74 \times 10^{-1}$ |             |
| <b>SEBS 9BS</b>    | $5.83 \times 10^{-1}$  | $6.96 \times 10^{-2}$ | $6.95 \times 10^{-1}$ | $8.30 \times 10^{-2}$ | $2.15 \times 10^{-1}$ |             |
| <b>SEBS 9B</b>     | $3.26 \times 10^{-1}$  | $5.26 \times 10^{-2}$ | $3.88 \times 10^{-1}$ | $6.27 \times 10^{-2}$ | $2.15 \times 10^{-1}$ |             |
| <b>SEBS 9BY</b>    | $2.26 \times 10^{-1}$  | $4.14 \times 10^{-2}$ | $2.69 \times 10^{-1}$ | $4.94 \times 10^{-2}$ | $2.15 \times 10^{-1}$ |             |
| <b>SEBS12BS</b>    | $5.27 \times 10^{-1}$  | $5.90 \times 10^{-2}$ | $6.28 \times 10^{-1}$ | $7.03 \times 10^{-2}$ | $1.60 \times 10^{-1}$ |             |
| <b>SEBS12B</b>     | $3.08 \times 10^{-1}$  | $4.71 \times 10^{-2}$ | $3.67 \times 10^{-1}$ | $5.61 \times 10^{-2}$ | $1.60 \times 10^{-1}$ |             |
| <b>SEBS12BY</b>    | $2.02 \times 10^{-1}$  | $3.64 \times 10^{-2}$ | $2.41 \times 10^{-1}$ | $4.33 \times 10^{-2}$ | $1.60 \times 10^{-1}$ |             |
| <b>SEBS15BS</b>    | $3.95 \times 10^{-1}$  | $5.01 \times 10^{-2}$ | $4.71 \times 10^{-1}$ | $5.97 \times 10^{-2}$ | $1.30 \times 10^{-1}$ |             |
| <b>SEBS15B</b>     | $2.31 \times 10^{-1}$  | $3.85 \times 10^{-2}$ | $2.75 \times 10^{-1}$ | $4.58 \times 10^{-2}$ | $1.29 \times 10^{-1}$ |             |
| <b>SEBS15BY</b>    | $1.52 \times 10^{-1}$  | $2.90 \times 10^{-2}$ | $1.81 \times 10^{-1}$ | $3.45 \times 10^{-2}$ | $1.29 \times 10^{-1}$ |             |
| <b>SEBS20B</b>     | $1.41 \times 10^{-1}$  | $2.47 \times 10^{-2}$ | $1.68 \times 10^{-1}$ | $2.94 \times 10^{-2}$ | $9.76 \times 10^{-2}$ |             |
| <b>SEBS20BY</b>    | $1.01 \times 10^{-1}$  | $1.95 \times 10^{-2}$ | $1.20 \times 10^{-1}$ | $2.32 \times 10^{-2}$ | $9.76 \times 10^{-2}$ |             |
| <b>SEBS 5WB</b>    | $4.51 \times 10^{-1}$  | $7.70 \times 10^{-2}$ | $5.37 \times 10^{-1}$ | $9.17 \times 10^{-2}$ | $1.96 \times 10^{-1}$ |             |
| <b>SEBS 5WBY</b>   | $3.25 \times 10^{-1}$  | $6.15 \times 10^{-2}$ | $3.88 \times 10^{-1}$ | $7.33 \times 10^{-2}$ | $1.96 \times 10^{-1}$ |             |
| <b>SEBS 7WBS</b>   | $5.83 \times 10^{-1}$  | $6.96 \times 10^{-2}$ | $6.95 \times 10^{-1}$ | $8.30 \times 10^{-2}$ | $1.40 \times 10^{-1}$ |             |
| <b>SEBS 7WB</b>    | $3.26 \times 10^{-1}$  | $5.26 \times 10^{-2}$ | $3.88 \times 10^{-1}$ | $6.27 \times 10^{-2}$ | $1.40 \times 10^{-1}$ |             |
| <b>SEBS 7WBY</b>   | $2.26 \times 10^{-1}$  | $4.14 \times 10^{-2}$ | $2.69 \times 10^{-1}$ | $4.94 \times 10^{-2}$ | $1.40 \times 10^{-1}$ |             |
| <b>SEBS 9WBS</b>   | $4.63 \times 10^{-1}$  | $6.05 \times 10^{-2}$ | $5.52 \times 10^{-1}$ | $7.21 \times 10^{-2}$ | $1.09 \times 10^{-1}$ |             |
| <b>SEBS 9WB</b>    | $2.41 \times 10^{-1}$  | $4.23 \times 10^{-2}$ | $2.87 \times 10^{-1}$ | $5.04 \times 10^{-2}$ | $1.08 \times 10^{-1}$ |             |
| <b>SEBS 9WBY</b>   | $1.71 \times 10^{-1}$  | $3.31 \times 10^{-2}$ | $2.03 \times 10^{-1}$ | $3.94 \times 10^{-2}$ | $1.08 \times 10^{-1}$ |             |
| <b>SEBS12WBS</b>   | $3.89 \times 10^{-1}$  | $5.28 \times 10^{-2}$ | $4.64 \times 10^{-1}$ | $6.29 \times 10^{-2}$ | $8.17 \times 10^{-2}$ |             |
| <b>SEBS12WB</b>    | $2.17 \times 10^{-1}$  | $3.81 \times 10^{-2}$ | $2.59 \times 10^{-1}$ | $4.55 \times 10^{-2}$ | $8.16 \times 10^{-2}$ |             |
| <b>SEBS12WBY</b>   | $1.51 \times 10^{-1}$  | $2.94 \times 10^{-2}$ | $1.79 \times 10^{-1}$ | $3.50 \times 10^{-2}$ | $8.16 \times 10^{-2}$ |             |
| <b>SEBS15WBS</b>   | $2.58 \times 10^{-1}$  | $4.06 \times 10^{-2}$ | $3.07 \times 10^{-1}$ | $4.83 \times 10^{-2}$ | $4.71 \times 10^{-2}$ |             |
| <b>SEBS15WB</b>    | $1.63 \times 10^{-1}$  | $3.03 \times 10^{-2}$ | $1.94 \times 10^{-1}$ | $3.61 \times 10^{-2}$ | $4.71 \times 10^{-2}$ |             |
| <b>SEBS15WBY</b>   | $1.13 \times 10^{-1}$  | $2.29 \times 10^{-2}$ | $1.35 \times 10^{-1}$ | $2.73 \times 10^{-2}$ | $4.71 \times 10^{-2}$ |             |

E<sub>P1</sub>: M<sub>P</sub> equivalent coefficient with 1 block usedE<sub>P2</sub>: M<sub>P</sub> equivalent coefficient with 2 blocks used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 block usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 blocks used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficient

Table 1-8 Slide Guide SEB and SER type

| part number         | equivalent coefficient |                       |                       |                       |                       | unit : 1/mm |
|---------------------|------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-------------|
|                     | E <sub>P1</sub>        | E <sub>P2</sub>       | E <sub>Y1</sub>       | E <sub>Y2</sub>       | E <sub>R</sub>        |             |
| <b>SEBS 2A</b>      | $7.06 \times 10^{-1}$  | $1.37 \times 10^{-1}$ | $5.92 \times 10^{-1}$ | $1.15 \times 10^{-1}$ | $9.09 \times 10^{-1}$ |             |
| <b>SEBS 3A</b>      | $9.16 \times 10^{-1}$  | $1.49 \times 10^{-1}$ | $7.69 \times 10^{-1}$ | $1.25 \times 10^{-1}$ | $6.25 \times 10^{-1}$ |             |
| <b>SEBS 3AY</b>     | $6.02 \times 10^{-1}$  | $1.13 \times 10^{-1}$ | $5.05 \times 10^{-1}$ | $9.48 \times 10^{-2}$ | $6.25 \times 10^{-1}$ |             |
| <b>SEBS 5A</b>      | $6.11 \times 10^{-1}$  | $1.01 \times 10^{-1}$ | $5.13 \times 10^{-1}$ | $8.46 \times 10^{-2}$ | $3.85 \times 10^{-1}$ |             |
| <b>SEBS 5AY</b>     | $4.65 \times 10^{-1}$  | $8.45 \times 10^{-2}$ | $3.90 \times 10^{-1}$ | $7.09 \times 10^{-2}$ | $3.85 \times 10^{-1}$ |             |
| <b>SEBS 7A</b>      | $4.62 \times 10^{-1}$  | $7.48 \times 10^{-2}$ | $3.87 \times 10^{-1}$ | $6.27 \times 10^{-2}$ | $2.74 \times 10^{-1}$ |             |
| <b>SEBS 7AY</b>     | $2.84 \times 10^{-1}$  | $5.49 \times 10^{-2}$ | $2.38 \times 10^{-1}$ | $4.61 \times 10^{-2}$ | $2.74 \times 10^{-1}$ |             |
| <b>SEB(S)9A</b>     | $3.32 \times 10^{-1}$  | $5.89 \times 10^{-2}$ | $2.78 \times 10^{-1}$ | $4.94 \times 10^{-2}$ | $2.20 \times 10^{-1}$ |             |
| <b>SEB(S)9AY</b>    | $2.25 \times 10^{-1}$  | $4.46 \times 10^{-2}$ | $1.89 \times 10^{-1}$ | $3.74 \times 10^{-2}$ | $2.20 \times 10^{-1}$ |             |
| <b>SEB(S)12A</b>    | $3.08 \times 10^{-1}$  | $5.62 \times 10^{-2}$ | $2.58 \times 10^{-1}$ | $4.72 \times 10^{-2}$ | $1.60 \times 10^{-1}$ |             |
| <b>SEB(S)12AY</b>   | $2.02 \times 10^{-1}$  | $4.11 \times 10^{-2}$ | $1.70 \times 10^{-1}$ | $3.45 \times 10^{-2}$ | $1.60 \times 10^{-1}$ |             |
| <b>SEB(S)15A</b>    | $2.31 \times 10^{-1}$  | $4.30 \times 10^{-2}$ | $1.94 \times 10^{-1}$ | $3.61 \times 10^{-2}$ | $1.29 \times 10^{-1}$ |             |
| <b>SEB(S)15AY</b>   | $1.52 \times 10^{-1}$  | $3.12 \times 10^{-2}$ | $1.27 \times 10^{-1}$ | $2.62 \times 10^{-2}$ | $1.29 \times 10^{-1}$ |             |
| <b>SEB(S)20A</b>    | $1.53 \times 10^{-1}$  | $3.03 \times 10^{-2}$ | $1.28 \times 10^{-1}$ | $2.54 \times 10^{-2}$ | $9.76 \times 10^{-2}$ |             |
| <b>SEB(S)20AY</b>   | $1.01 \times 10^{-1}$  | $2.16 \times 10^{-2}$ | $8.44 \times 10^{-2}$ | $1.81 \times 10^{-2}$ | $9.76 \times 10^{-2}$ |             |
| <b>SEBS 3WA</b>     | $6.74 \times 10^{-1}$  | $1.14 \times 10^{-1}$ | $5.42 \times 10^{-1}$ | $9.58 \times 10^{-2}$ | $3.23 \times 10^{-1}$ |             |
| <b>SEBS 3WAY</b>    | $4.48 \times 10^{-1}$  | $8.78 \times 10^{-2}$ | $3.76 \times 10^{-1}$ | $7.37 \times 10^{-2}$ | $3.23 \times 10^{-1}$ |             |
| <b>SEBS 7WA(D)</b>  | $3.26 \times 10^{-1}$  | $5.56 \times 10^{-2}$ | $2.73 \times 10^{-1}$ | $4.67 \times 10^{-2}$ | $1.40 \times 10^{-1}$ |             |
| <b>SEBS 7WAY</b>    | $2.26 \times 10^{-1}$  | $4.32 \times 10^{-2}$ | $1.90 \times 10^{-1}$ | $3.63 \times 10^{-2}$ | $1.40 \times 10^{-1}$ |             |
| <b>SEB(S)9WA(D)</b> | $2.41 \times 10^{-1}$  | $4.72 \times 10^{-2}$ | $2.02 \times 10^{-1}$ | $3.96 \times 10^{-2}$ | $1.08 \times 10^{-1}$ |             |
| <b>SEB(S)9WAY</b>   | $1.71 \times 10^{-1}$  | $3.58 \times 10^{-2}$ | $1.43 \times 10^{-1}$ | $3.00 \times 10^{-2}$ | $1.08 \times 10^{-1}$ |             |
| <b>SEB(S)12WA</b>   | $2.02 \times 10^{-1}$  | $4.13 \times 10^{-2}$ | $1.70 \times 10^{-1}$ | $3.46 \times 10^{-2}$ | $8.16 \times 10^{-2}$ |             |
| <b>SEB(S)12WAY</b>  | $1.43 \times 10^{-1}$  | $3.10 \times 10^{-2}$ | $1.20 \times 10^{-1}$ | $2.60 \times 10^{-2}$ | $8.16 \times 10^{-2}$ |             |
| <b>SEB(S)15WA</b>   | $1.63 \times 10^{-1}$  | $3.29 \times 10^{-2}$ | $1.37 \times 10^{-1}$ | $2.76 \times 10^{-2}$ | $4.71 \times 10^{-2}$ |             |
| <b>SEB(S)15WAY</b>  | $1.13 \times 10^{-1}$  | $2.43 \times 10^{-2}$ | $9.48 \times 10^{-2}$ | $2.04 \times 10^{-2}$ | $4.71 \times 10^{-2}$ |             |
| <b>SER(S)9A</b>     | $2.49 \times 10^{-1}$  | $4.15 \times 10^{-2}$ | $2.15 \times 10^{-1}$ | $3.58 \times 10^{-2}$ | $1.50 \times 10^{-1}$ |             |
| <b>SER(S)12A</b>    | $2.50 \times 10^{-1}$  | $4.16 \times 10^{-2}$ | $2.23 \times 10^{-1}$ | $3.71 \times 10^{-2}$ | $1.33 \times 10^{-1}$ |             |
| <b>SER(S)15A</b>    | $1.99 \times 10^{-1}$  | $3.32 \times 10^{-2}$ | $1.79 \times 10^{-1}$ | $2.98 \times 10^{-2}$ | $1.05 \times 10^{-1}$ |             |
| <b>SER(S)20A</b>    | $1.66 \times 10^{-1}$  | $2.77 \times 10^{-2}$ | $1.47 \times 10^{-1}$ | $2.45 \times 10^{-2}$ | $6.49 \times 10^{-2}$ |             |
| <b>SER(S)9WA</b>    | $1.52 \times 10^{-1}$  | $2.53 \times 10^{-2}$ | $1.36 \times 10^{-1}$ | $2.26 \times 10^{-2}$ | $7.17 \times 10^{-2}$ |             |
| <b>SER(S)12WA</b>   | $1.42 \times 10^{-1}$  | $2.36 \times 10^{-2}$ | $1.28 \times 10^{-1}$ | $2.13 \times 10^{-2}$ | $5.86 \times 10^{-2}$ |             |
| <b>SER(S)15WA</b>   | $1.60 \times 10^{-1}$  | $2.66 \times 10^{-2}$ | $1.45 \times 10^{-1}$ | $2.41 \times 10^{-2}$ | $4.15 \times 10^{-2}$ |             |

E<sub>P1</sub>: M<sub>P</sub> equivalent coefficient with 1 block usedE<sub>P2</sub>: M<sub>P</sub> equivalent coefficient with 2 blocks used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 block usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 blocks used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficient

Table 1-9 Slide Guide SGL, SGW type

| part number                | equivalent coefficient |                       |                       |                       |                       | unit : 1/mm |
|----------------------------|------------------------|-----------------------|-----------------------|-----------------------|-----------------------|-------------|
|                            | E <sub>P1</sub>        | E <sub>P2</sub>       | E <sub>Y1</sub>       | E <sub>Y2</sub>       | E <sub>R</sub>        |             |
| <b>SGL15F (E)</b>          | $2.57 \times 10^{-1}$  | $3.75 \times 10^{-2}$ | $2.57 \times 10^{-1}$ | $3.75 \times 10^{-2}$ | $1.28 \times 10^{-1}$ |             |
| <b>SGL20F (E)</b>          | $2.06 \times 10^{-1}$  | $3.31 \times 10^{-2}$ | $2.06 \times 10^{-1}$ | $3.31 \times 10^{-2}$ | $9.31 \times 10^{-2}$ |             |
| <b>SGL25F (E)</b>          | $1.72 \times 10^{-1}$  | $2.81 \times 10^{-2}$ | $1.72 \times 10^{-1}$ | $2.81 \times 10^{-2}$ | $8.31 \times 10^{-2}$ |             |
| <b>SGL30F (E)</b>          | $1.47 \times 10^{-1}$  | $2.28 \times 10^{-2}$ | $1.47 \times 10^{-1}$ | $2.28 \times 10^{-2}$ | $6.88 \times 10^{-2}$ |             |
| <b>SGL35F (E)</b>          | $1.29 \times 10^{-1}$  | $2.02 \times 10^{-2}$ | $1.29 \times 10^{-1}$ | $2.02 \times 10^{-2}$ | $5.45 \times 10^{-2}$ |             |
| <b>SGL15TF (TE)</b>        | $1.63 \times 10^{-1}$  | $2.87 \times 10^{-2}$ | $1.63 \times 10^{-1}$ | $2.87 \times 10^{-2}$ | $1.29 \times 10^{-1}$ |             |
| <b>SGL20TF (TE)</b>        | $1.41 \times 10^{-1}$  | $2.59 \times 10^{-2}$ | $1.41 \times 10^{-1}$ | $2.59 \times 10^{-2}$ | $9.28 \times 10^{-2}$ |             |
| <b>SGL25TF (TE)</b>        | $1.09 \times 10^{-1}$  | $2.09 \times 10^{-2}$ | $1.09 \times 10^{-1}$ | $2.09 \times 10^{-2}$ | $8.31 \times 10^{-2}$ |             |
| <b>SGL30TF (TE)</b>        | $9.32 \times 10^{-2}$  | $1.71 \times 10^{-2}$ | $9.32 \times 10^{-2}$ | $1.71 \times 10^{-2}$ | $6.87 \times 10^{-2}$ |             |
| <b>SGL35TF (TE)</b>        | $8.14 \times 10^{-2}$  | $1.51 \times 10^{-2}$ | $8.14 \times 10^{-2}$ | $1.51 \times 10^{-2}$ | $5.49 \times 10^{-2}$ |             |
| <b>SGL15HTF (HTE,HTEX)</b> | $1.63 \times 10^{-1}$  | $2.87 \times 10^{-2}$ | $1.63 \times 10^{-1}$ | $2.87 \times 10^{-2}$ | $1.29 \times 10^{-1}$ |             |
| <b>SGL20HTF (HTE,HTEX)</b> | $1.22 \times 10^{-1}$  | $2.33 \times 10^{-2}$ | $1.22 \times 10^{-1}$ | $2.33 \times 10^{-2}$ | $9.29 \times 10^{-2}$ |             |
| <b>SGL25HTF (HTE,HTEX)</b> | $1.09 \times 10^{-1}$  | $2.09 \times 10^{-2}$ | $1.09 \times 10^{-1}$ | $2.09 \times 10^{-2}$ | $8.31 \times 10^{-2}$ |             |
| <b>SGL30HTF (HTE,HTEX)</b> | $9.32 \times 10^{-2}$  | $1.71 \times 10^{-2}$ | $9.32 \times 10^{-2}$ | $1.71 \times 10^{-2}$ | $6.87 \times 10^{-2}$ |             |
| <b>SGL35HTF (HTE,HTEX)</b> | $8.14 \times 10^{-2}$  | $1.51 \times 10^{-2}$ | $8.14 \times 10^{-2}$ | $1.51 \times 10^{-2}$ | $5.49 \times 10^{-2}$ |             |
| <b>SGL45HTF (HTE,HTEX)</b> | $6.52 \times 10^{-2}$  | $1.22 \times 10^{-2}$ | $6.52 \times 10^{-2}$ | $1.22 \times 10^{-2}$ | $4.37 \times 10^{-2}$ |             |
| <b>SGL15HYF (HYE)</b>      | $1.08 \times 10^{-1}$  | $2.13 \times 10^{-2}$ | $1.08 \times 10^{-1}$ | $2.13 \times 10^{-2}$ | $1.28 \times 10^{-1}$ |             |
| <b>SGL20HYF (HYE)</b>      | $8.61 \times 10^{-2}$  | $1.79 \times 10^{-2}$ | $8.61 \times 10^{-2}$ | $1.79 \times 10^{-2}$ | $9.31 \times 10^{-2}$ |             |
| <b>SGL25HYF (HYE)</b>      | $7.54 \times 10^{-2}$  | $1.57 \times 10^{-2}$ | $7.54 \times 10^{-2}$ | $1.57 \times 10^{-2}$ | $8.32 \times 10^{-2}$ |             |
| <b>SGL30HYF (HYE)</b>      | $6.47 \times 10^{-2}$  | $1.30 \times 10^{-2}$ | $6.47 \times 10^{-2}$ | $1.30 \times 10^{-2}$ | $6.90 \times 10^{-2}$ |             |
| <b>SGL35HYF (HYE)</b>      | $5.65 \times 10^{-2}$  | $1.15 \times 10^{-2}$ | $5.65 \times 10^{-2}$ | $1.15 \times 10^{-2}$ | $5.46 \times 10^{-2}$ |             |
| <b>SGL45HYF (HYE)</b>      | $5.00 \times 10^{-2}$  | $1.01 \times 10^{-2}$ | $5.00 \times 10^{-2}$ | $1.01 \times 10^{-2}$ | $4.35 \times 10^{-2}$ |             |
| <b>SGW17TF (TE)</b>        | $2.00 \times 10^{-1}$  | $3.28 \times 10^{-2}$ | $2.00 \times 10^{-1}$ | $3.28 \times 10^{-2}$ | $5.35 \times 10^{-2}$ |             |
| <b>SGW21TF (TE)</b>        | $1.67 \times 10^{-1}$  | $2.89 \times 10^{-2}$ | $1.67 \times 10^{-1}$ | $2.89 \times 10^{-2}$ | $4.78 \times 10^{-2}$ |             |
| <b>SGW27TF (TE)</b>        | $1.26 \times 10^{-1}$  | $2.31 \times 10^{-2}$ | $1.26 \times 10^{-1}$ | $2.31 \times 10^{-2}$ | $4.33 \times 10^{-2}$ |             |
| <b>SGW35TF (TE)</b>        | $8.39 \times 10^{-2}$  | $1.56 \times 10^{-2}$ | $8.39 \times 10^{-2}$ | $1.56 \times 10^{-2}$ | $2.62 \times 10^{-2}$ |             |

E<sub>P1</sub>: M<sub>P</sub> equivalent coefficient with 1 block usedE<sub>P2</sub>: M<sub>P</sub> equivalent coefficient with 2 blocks used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 block usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 blocks used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficientE<sub>P1</sub>: M<sub>P</sub> equivalent coefficient with 1 nut usedE<sub>P2</sub>: M<sub>P</sub> equivalent coefficient with 2 nuts used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 nut usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 nuts used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficientE<sub>P1</sub>: M<sub>P</sub> equivalent coefficient with 1 nut usedE<sub>P2</sub>: M<sub>P</sub> equivalent coefficient with 2 nuts used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 nut usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 nuts used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficient

unit : 1/mm

Table 1-10 Ball Spline · Rotary Ball Spline unit : 1/mm

| part number    | equivalent coefficient |                    | unit : 1/mm                                 |
|----------------|------------------------|--------------------|---|
|                | E <sub>1</sub>         | E <sub>2</sub>     |   |
| <b>SSP 4</b>   | —                      | —                  | $6.19 \times 10^{-1}$ $1.18 \times 10^{-1}$ |
| <b>SSP 6</b>   | <b>SPR 6</b>           | <b>SPB 6 KP</b>    | $4.47 \times 10^{-1}$ $5.70 \times 10^{-2}$ |
| <b>SSP 8</b>   | <b>SPR 8</b>           | <b>SPB 8 KP</b>    | $3.88 \times 10^{-1}$ $5.74 \times 10^{-2}$ |
| <b>SSP 10</b>  | <b>SPR 10</b>          | <b>SPB 10 KP</b>   | $2.82 \times 10^{-1}$ $4.37 \times 10^{-2}$ |
| <b>SSP 13A</b> | <b>SPR 13</b>          | <b>SPB 13 KP</b>   | $3.57 \times 10^{-1}$ $4.49 \times 10^{-2}$ |
| <b>SSP 16A</b> | <b>SPR 16</b>          | <b>SPB 16 (KP)</b> | $2.43 \times 10^{-1}$ $3.75 \times 10^{-2}$ |
| <b>SSP 20A</b> | <b>SPR 20A</b>         | <b>SPB 20 (KP)</b> | $1.48 \times 10^{-1}$ $2.91 \times 10^{-2}$ |
| <b>SSP 25A</b> | <b>SPR 25A</b>         | <b>SPB 25 (KP)</b> | $1.37 \times 10^{-1}$ $2.27 \times 10^{-2}$ |
| <b>SSP 30A</b> | <b>SPR 30A</b>         | —                  | $1.28 \times 10^{-1}$ $1.58 \times 10^{-2}$ |
| <b>SSP 40A</b> | <b>SPR 40A</b>         | —                  | $1.05 \times 10^{-1}$ $1.28 \times 10^{-2}$ |
| <b>SSP 50A</b> | <b>SPR 50A</b>         | —                  | $9.41 \times 10^{-2}$ $1.59 \times 10^{-2}$ |
| <b>SSP 60A</b> | <b>SPR 60A</b>         | —                  | $9.02 \times 10^{-2}$ $1.45 \times 10^{-2}$ |
| <b>SSP 80</b>  | —                      | —                  | $6.70 \times 10^{-2}$ $1.21 \times 10^{-2}$ |
| <b>SSP 80L</b> | —                      | —                  | $4.56 \times 10^{-2}$ $9.53 \times 10^{-3}$ |
| <b>SSP100</b>  | —                      | —                  | $5.92 \times 10^{-2}$ $1.03 \times 10^{-2}$ |
| <b>SSP100L</b> | —                      | —                  | $4.06 \times 10^{-2}$ $7.90 \times 10^{-3}$ |
| <b>SSP 20</b>  | <b>SPR 20</b>          | —                  | $1.79 \times 10^{-1}$ $2.26 \times 10^{-2}$ |
| <b>SSP 25</b>  | <b>SPR 25</b>          | —                  | $1.55 \times 10^{-1}$ $1.94 \times 10^{-2}$ |
| <b>SSP 30</b>  | <b>SPR 30</b>          | —                  | $1.28 \times 10^{-1}$ $1.58 \times 10^{-2}$ |
| <b>SSP 40</b>  | <b>SPR 40</b>          | —                  | $1.05 \times 10^{-1}$ $1.28 \times 10^{-2}$ |
| <b>SSP 50</b>  | <b>SPR 50</b>          | —                  | $1.07 \times 10^{-1}$ $1.69 \times 10^{-2}$ |
| <b>SSP 60</b>  | <b>SPR 60</b>          | —                  | $9.77 \times 10^{-2}$ $1.44 \times 10^{-2}$ |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contactE<sub>1</sub>: equivalent moment coefficient with 1 nut usedE<sub>2</sub>: equivalent moment coefficient with 2 nuts used in close contact

unit : 1/mm

| part number    | equivalent coefficient |                       |                       |                       | unit : 1/mm |
|----------------|------------------------|-----------------------|-----------------------|-----------------------|-------------|
|                | E <sub>P1</sub>        | E <sub>P2</sub>       | E <sub>Y1</sub>       | E <sub>Y2</sub>       |             |
| <b>SSP 4AM</b> | $7.42 \times 10^{-1}$  | $1.30 \times 10^{-1}$ | $4.25 \times 10^{-1}$ | $7.50 \times 10^{-2}$ |             |
| <b>SSP 5AM</b> | $5.52 \times 10^{-1}$  | $8.70 \times 10^{-2}$ | $4.53 \times 10^{-1}$ | $7.10 \times 10^{-2}$ |             |
| <b>SSP 6AM</b> | $5.06 \times 10^{-1}$  | $7.80 \times 10^{-2}$ | $4.15 \times 10^{-1}$ | $6.40 \times 10^{-2}$ |             |
| <b>SSP 8AM</b> | $4.40 \times 10^{-1}$  | $6.50 \times 10^{-2}$ | $3.62 \times 10^{-1}$ | $5.40 \times 10^{-2}$ |             |
| <b>SSP10AM</b> | $3.66 \times 10^{-1}$  | $5.50 \times 10^{-2}$ | $3.01 \times 10^{-1}$ | $4.50 \times 10^{-2}$ |             |

E<sub>P1</sub>: M<sub>P</sub> equivalent coefficient with 1 nut usedE<sub>P2</sub>: M<sub>P</sub> equivalent coefficient with 2 nuts used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 nut usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 nuts used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficient

Table 1-11 Slide Bush SM type unit : 1/mm

| part number  | equivalent coefficient |                       | unit : 1/mm |
|--------------|------------------------|-----------------------|-------------|
|              | E <sub>1</sub>         | E <sub>2</sub>        |             |
| <b>SM 3</b>  | 1.24                   | $2.13 \times 10^{-1}$ |             |
| <b>SM 4</b>  | 1.21                   | $1.78 \times 10^{-1}$ |             |
| <b>SM 5</b>  | $8.96 \times 10^{-1}$  | $1.40 \times 10^{-1}$ |             |
| <b>SM 6</b>  | $7.29 \times 10^{-1}$  | $1.09 \times 10^{-1}$ |             |
| <b>SM 8s</b> | $7.19 \times 10^{-1}$  | $1.20 \times 10^{-1}$ |             |
| <b>SM 8</b>  | $5.46 \times 10^{-1}$  | $8.42 \times 10^{-2}$ |             |
| <b>SM 10</b> | $4.55 \times 10^{-1}$  | $7.02 \times 10^{-2}$ |             |
| <b>SM 12</b> | $4.32 \times 10^{-1}$  | $6.64 \times 10^{-2}$ |             |
| <b>SM 13</b> | $4.06 \times 10^{-1}$  | $6.21 \times 10^{-2}$ |             |
| <b>SM 16</b> | $3.59 \times 10^{-1}$  | $5.46 \times 10^{-2}$ |             |
| <b>SM 20</b> | $3.07 \times 10^{-1}$  | $4.70 \times 10^{-2}$ |             |
| <b>SM 25</b> | $2.17 \times 10^{-1}$  | $3.33 \times 10^{-2}$ |             |
| <b>SM 30</b> | $1.99 \times 10^{-1}$  | $3.07 \times 10^{-2}$ |             |
| <b>SM 35</b> | $1.71 \times 10^{-1}$  | $2.70 \times 10^{-2}$ |             |
| <b>SM 40</b> | $1.64 \times 10^{-1}$  | $2.51 \times 10^{-2}$ |             |
| <b>SM 50</b> | $1.20 \times 10^{-1}$  | $1.89 \times 10^{-2}$ |             |
| <b>SM 60</b> | $1.13 \times 10^{-1}$  | $1.75 \times 10^{-2}$ |             |
| <b>SM 80</b> | $8.18 \times 10^{-2}$  | $1.36 \times 10^{-2}$ |             |
| <b>SM100</b> | $6.66 \times 10^{-2}$  | $1.11 \times 10^{-2}$ |             |
| <b>SM120</b> | $5.63 \times 10^{-2}$  | $9.38 \times 10^{-3}$ |             |
| <b>SM150</b> | $4.62 \times 10^{-2}$  | $7.71 \times 10^{-3}$ |             |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contactE<sub>1</sub>: equivalent moment coefficient with 1 nut usedE<sub>2</sub>: equivalent moment coefficient with 2 nuts used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficientE<sub>1</sub>: equivalent coefficient with 1 nut usedE<sub>2</sub>: equivalent coefficient with 2 nuts used in close contactE<sub>Y1</sub>: M<sub>Y</sub> equivalent coefficient with 1 nut usedE<sub>Y2</sub>: M<sub>Y</sub> equivalent coefficient with 2 nuts used in close contactE<sub>R</sub>: M<sub>R</sub> equivalent coefficient

Table 1-13 Slide Bush SM-W type unit : 1/mm

| part number   | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub> |
|---------------|--|----------------|
| <b>SM 3W</b>  | $4.12 \times 10^{-1}$                    | —              |
| <b>SM 4W</b>  | $4.03 \times 10^{-1}$                    | —              |
| <b>SM 5W</b>  | $2.99 \times 10^{-1}$                    | —              |
| <b>SM 6W</b>  | $2.43 \times 10^{-1}$                    | —              |
| <b>SM 8W</b>  | $1.82 \times 10^{-1}$                    | —              |
| <b>SM 10W</b> | $1.52 \times 10^{-1}$                    | —              |
| <b>SM 12W</b> | $1.44 \times 10^{-1}$                    | —              |
| <b>SM 13W</b> | $1.35 \times 10^{-1}$                    | —              |
| <b>SM 16W</b> | $1.19 \times 10^{-1}$                    | —              |
| <b>SM 20W</b> | $1.02 \times 10^{-1}$                    | —              |
| <b>SM 25W</b> | $7.24 \times 10^{-2}$                    | —              |
| <b>SM 30W</b> | $6.63 \times 10^{-2}$                    | —              |
| <b>SM 35W</b> | $5.70 \times 10^{-2}$                    | —              |
| <b>SM 40W</b> | $5.47 \times 10^{-2}$                    | —              |
| <b>SM 50W</b> | $4.01 \times 10^{-2}$                    | —              |
| <b>SM 60W</b> | $3.77 \times 10^{-2}$                    | —              |

E<sub>1</sub>: equivalent coefficient with 1 bush used

Table 1-14 Slide Bush TRF type unit : 1/mm

| part number  | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub> |
|--------------|--|----------------|
| <b>TRF 6</b> | $6.46 \times 10^{-2}$                    | —              |
| <b>TRF 8</b> | $4.90 \times 10^{-2}$                    | —              |
| <b>TRF10</b> | $4.07 \times 10^{-2}$                    | —              |
| <b>TRF12</b> | $3.92 \times 10^{-2}$                    | —              |
| <b>TRF13</b> | $3.66 \times 10^{-2}$                    | —              |
| <b>TRF16</b> | $3.20 \times 10^{-2}$                    | —              |
| <b>TRF20</b> | $2.80 \times 10^{-2}$                    | —              |
| <b>TRF25</b> | $2.00 \times 10^{-2}$                    | —              |
| <b>TRF30</b> | $1.85 \times 10^{-2}$                    | —              |
| <b>TRF35</b> | $1.68 \times 10^{-2}$                    | —              |
| <b>TRF40</b> | $1.45 \times 10^{-2}$                    | —              |
| <b>TRF50</b> | $1.16 \times 10^{-2}$                    | —              |
| <b>TRF60</b> | $1.11 \times 10^{-2}$                    | —              |

E<sub>1</sub>: equivalent coefficient with 1 bush used

Table 1-15

Slide Bush KB type unit : 1/mm

| part number  | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub>        |
|--------------|--|-----------------------|
| <b>KB 3</b>  | 1.28                                     | $2.13 \times 10^{-1}$ |
| <b>KB 4</b>  | 1.05                                     | $1.75 \times 10^{-1}$ |
| <b>KB 5</b>  | $5.40 \times 10^{-1}$                    | $9.00 \times 10^{-2}$ |
| <b>KB 8</b>  | $5.61 \times 10^{-1}$                    | $8.00 \times 10^{-2}$ |
| <b>KB10</b>  | $4.21 \times 10^{-1}$                    | $7.02 \times 10^{-2}$ |
| <b>KB12</b>  | $4.02 \times 10^{-1}$                    | $6.20 \times 10^{-2}$ |
| <b>KB16</b>  | $3.77 \times 10^{-1}$                    | $5.73 \times 10^{-2}$ |
| <b>KB20</b>  | $3.29 \times 10^{-1}$                    | $4.49 \times 10^{-2}$ |
| <b>KB25</b>  | $2.14 \times 10^{-1}$                    | $3.37 \times 10^{-2}$ |
| <b>KB30</b>  | $2.08 \times 10^{-1}$                    | $2.96 \times 10^{-2}$ |
| <b>KB40</b>  | $1.64 \times 10^{-1}$                    | $2.51 \times 10^{-2}$ |
| <b>KB50</b>  | $1.20 \times 10^{-1}$                    | $1.89 \times 10^{-2}$ |
| <b>KB60</b>  | $1.21 \times 10^{-1}$                    | $1.55 \times 10^{-2}$ |
| <b>KB80</b>  | $7.34 \times 10^{-2}$                    | $1.22 \times 10^{-2}$ |
| <b>KB 8W</b> | $1.87 \times 10^{-1}$                    | —                     |
| <b>KB12W</b> | $1.34 \times 10^{-1}$                    | —                     |
| <b>KB16W</b> | $1.25 \times 10^{-1}$                    | —                     |
| <b>KB20W</b> | $1.10 \times 10^{-1}$                    | —                     |
| <b>KB25W</b> | $7.14 \times 10^{-2}$                    | —                     |
| <b>KB30W</b> | $6.96 \times 10^{-2}$                    | —                     |
| <b>KB40W</b> | $5.47 \times 10^{-2}$                    | —                     |
| <b>KB50W</b> | $4.02 \times 10^{-2}$                    | —                     |
| <b>KB60W</b> | $4.11 \times 10^{-2}$                    | —                     |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contact

Table 1-16 TOPBALL TK type unit : 1/mm

| part number | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub>        |
|-------------|--|-----------------------|
| <b>TK 8</b> | $4.91 \times 10^{-1}$                    | $8.18 \times 10^{-2}$ |
| <b>TK10</b> | $4.17 \times 10^{-1}$                    | $6.95 \times 10^{-2}$ |
| <b>TK12</b> | $3.70 \times 10^{-1}$                    | $6.17 \times 10^{-2}$ |
| <b>TK16</b> | $3.30 \times 10^{-1}$                    | $5.49 \times 10^{-2}$ |
| <b>TK20</b> | $2.55 \times 10^{-1}$                    | $4.24 \times 10^{-2}$ |
| <b>TK25</b> | $1.90 \times 10^{-1}$                    | $3.16 \times 10^{-2}$ |
| <b>TK30</b> | $1.66 \times 10^{-1}$                    | $2.76 \times 10^{-2}$ |
| <b>TK40</b> | $1.42 \times 10^{-1}$                    | $2.36 \times 10^{-2}$ |
| <b>TK50</b> | $1.11 \times 10^{-1}$                    | $1.84 \times 10^{-2}$ |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contact

Table 1-17 TOPBALL TW type unit : 1/mm

| part number | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub>        |
|-------------|--|-----------------------|
| <b>TW 3</b> | $8.70 \times 10^{-1}$                    | $1.45 \times 10^{-1}$ |
| <b>TW 4</b> | $6.57 \times 10^{-1}$                    | $1.09 \times 10^{-1}$ |
| <b>TW 6</b> | $5.17 \times 10^{-1}$                    | $8.60 \times 10^{-2}$ |
| <b>TW 8</b> | $3.55 \times 10^{-1}$                    | $5.90 \times 10^{-2}$ |
| <b>TW10</b> | $3.00 \times 10^{-1}$                    | $5.00 \times 10^{-2}$ |
| <b>TW12</b> | $2.66 \times 10^{-1}$                    | $4.40 \times 10^{-2}$ |
| <b>TW16</b> | $1.90 \times 10^{-1}$                    | $3.10 \times 10^{-2}$ |
| <b>TW20</b> | $1.66 \times 10^{-1}$                    | $2.70 \times 10^{-2}$ |
| <b>TW24</b> | $1.44 \times 10^{-1}$                    | $2.40 \times 10^{-2}$ |
| <b>TW32</b> | $1.08 \times 10^{-1}$                    | $1.80 \times 10^{-2}$ |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contact

Table 1-19 Slide Bush GM type unit : 1/mm

| part number  | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub>        |
|--------------|--|-----------------------|
| <b>GM 6</b>  | $6.43 \times 10^{-1}$                    | $1.08 \times 10^{-1}$ |
| <b>GM 8</b>  | $4.92 \times 10^{-1}$                    | $8.20 \times 10^{-2}$ |
| <b>GM10</b>  | $4.21 \times 10^{-1}$                    | $7.01 \times 10^{-2}$ |
| <b>GM12</b>  | $3.85 \times 10^{-1}$                    | $6.42 \times 10^{-2}$ |
| <b>GM13</b>  | $3.78 \times 10^{-1}$                    | $6.29 \times 10^{-2}$ |
| <b>GM16</b>  | $3.25 \times 10^{-1}$                    | $5.42 \times 10^{-2}$ |
| <b>GM20</b>  | $2.75 \times 10^{-1}$                    | $4.58 \times 10^{-2}$ |
| <b>GM25</b>  | $1.98 \times 10^{-1}$                    | $3.30 \times 10^{-2}$ |
| <b>GM30</b>  | $1.82 \times 10^{-1}$                    | $3.03 \times 10^{-2}$ |
| <b>GM 6W</b> | $3.54 \times 10^{-1}$                    | $6.53 \times 10^{-2}$ |
| <b>GM 8W</b> | $2.38 \times 10^{-1}$                    | $4.96 \times 10^{-2}$ |
| <b>GM10W</b> | $2.20 \times 10^{-1}$                    | $4.50 \times 10^{-2}$ |
| <b>GM12W</b> | $2.07 \times 10^{-1}$                    | $3.81 \times 10^{-2}$ |
| <b>GM13W</b> | $1.94 \times 10^{-1}$                    | $3.76 \times 10^{-2}$ |
| <b>GM16W</b> | $1.71 \times 10^{-1}$                    | $3.44 \times 10^{-2}$ |
| <b>GM20W</b> | $1.37 \times 10^{-1}$                    | $2.69 \times 10^{-2}$ |
| <b>GM25W</b> | $9.03 \times 10^{-2}$                    | $1.94 \times 10^{-2}$ |
| <b>GM30W</b> | $9.55 \times 10^{-2}$                    | $1.78 \times 10^{-2}$ |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contact

Table 1-20 Slide Rotary Bush unit : 1/mm

| part number  | equivalent coefficient<br>E <sub>1</sub> | E <sub>2</sub>        |
|--------------|--|-----------------------|
| <b>SRE 6</b> | $6.83 \times 10^{-1}$                    | $1.14 \times 10^{-1}$ |
| <b>SRE 8</b> | $4.98 \times 10^{-1}$                    | $8.31 \times 10^{-2}$ |
| <b>SRE10</b> | $4.12 \times 10^{-1}$                    | $6.86 \times 10^{-2}$ |
| <b>SRE12</b> | $4.19 \times 10^{-1}$                    | $6.98 \times 10^{-2}$ |
| <b>SRE13</b> | $3.93 \times 10^{-1}$                    | $6.54 \times 10^{-2}$ |
| <b>SRE16</b> | $3.40 \times 10^{-1}$                    | $5.66 \times 10^{-2}$ |
| <b>SRE20</b> | $2.90 \times 10^{-1}$                    | $4.84 \times 10^{-2}$ |
| <b>SRE25</b> | $1.98 \times 10^{-1}$                    | $3.29 \times 10^{-2}$ |
| <b>SRE30</b> | $1.80 \times 10^{-1}$                    | $3.01 \times 10^{-2}$ |
| <b>SRE40</b> | $1.52 \times 10^{-1}$                    | $2.54 \times 10^{-2}$ |
| <b>RK12</b>  | $4.32 \times 10^{-1}$                    | $6.64 \times 10^{-2}$ |
| <b>RK16</b>  | $3.59 \times 10^{-1}$                    | $5.46 \times 10^{-2}$ |
| <b>RK20</b>  | $3.07 \times 10^{-1}$                    | $4.70 \times 10^{-2}$ |
| <b>RK25</b>  | $2.17 \times 10^{-1}$                    | $3.33 \times 10^{-2}$ |
| <b>RK30</b>  | $1.99 \times 10^{-1}$                    | $3.07 \times 10^{-2}$ |

E<sub>1</sub>: equivalent coefficient with 1 bush usedE<sub>2</sub>: equivalent coefficient with 2 bushes used in close contact

Table 1-21 Slide Table NVT type (1) unit: 1/mm

| part number    | equivalent coefficient |                       |                       |
|----------------|------------------------|-----------------------|-----------------------|
|                | E <sub>P</sub>         | E <sub>Y</sub>        | E <sub>R</sub>        |
| <b>NVT1025</b> | 2.27×10 <sup>-1</sup>  | 2.67×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>NVT1035</b> | 9.54×10 <sup>-1</sup>  | 3.98×10 <sup>-1</sup> | 8.75×10 <sup>-1</sup> |
| <b>NVT1045</b> | 2.79×10 <sup>-1</sup>  | 2.46×10 <sup>-1</sup> | 3.31×10 <sup>-1</sup> |
| <b>NVT1055</b> | 2.40×10 <sup>-1</sup>  | 2.03×10 <sup>-1</sup> | 3.51×10 <sup>-1</sup> |
| <b>NVT1065</b> | 1.70×10 <sup>-1</sup>  | 1.58×10 <sup>-1</sup> | 2.77×10 <sup>-1</sup> |
| <b>NVT1075</b> | 1.53×10 <sup>-1</sup>  | 1.38×10 <sup>-1</sup> | 2.95×10 <sup>-1</sup> |
| <b>NVT1085</b> | 1.24×10 <sup>-1</sup>  | 1.17×10 <sup>-1</sup> | 2.58×10 <sup>-1</sup> |
| <b>NVT2035</b> | 1.51×10 <sup>-1</sup>  | 1.74×10 <sup>-1</sup> | 1.12×10 <sup>-1</sup> |
| <b>NVT2050</b> | 1.62×10 <sup>-1</sup>  | 1.63×10 <sup>-1</sup> | 1.45×10 <sup>-1</sup> |
| <b>NVT2065</b> | 1.25×10 <sup>-1</sup>  | 1.29×10 <sup>-1</sup> | 1.32×10 <sup>-1</sup> |
| <b>NVT2080</b> | 1.15×10 <sup>-1</sup>  | 1.14×10 <sup>-1</sup> | 1.54×10 <sup>-1</sup> |
| <b>NVT2095</b> | 9.51×10 <sup>-2</sup>  | 9.56×10 <sup>-2</sup> | 1.43×10 <sup>-1</sup> |
| <b>NVT2110</b> | 8.81×10 <sup>-2</sup>  | 8.63×10 <sup>-2</sup> | 1.57×10 <sup>-1</sup> |
| <b>NVT2125</b> | 8.22×10 <sup>-2</sup>  | 7.88×10 <sup>-2</sup> | 1.69×10 <sup>-1</sup> |
| <b>NVT2140</b> | 7.13×10 <sup>-2</sup>  | 6.94×10 <sup>-2</sup> | 1.59×10 <sup>-1</sup> |
| <b>NVT2155</b> | 6.48×10 <sup>-2</sup>  | 6.26×10 <sup>-2</sup> | 1.69×10 <sup>-1</sup> |
| <b>NVT2170</b> | 6.10×10 <sup>-2</sup>  | 5.81×10 <sup>-2</sup> | 1.76×10 <sup>-1</sup> |
| <b>NVT2185</b> | 5.77×10 <sup>-2</sup>  | 5.42×10 <sup>-2</sup> | 1.82×10 <sup>-1</sup> |
| <b>NVT3055</b> | 3.41×10 <sup>-1</sup>  | 2.17×10 <sup>-1</sup> | 1.97×10 <sup>-1</sup> |
| <b>NVT3080</b> | 9.64×10 <sup>-2</sup>  | 1.02×10 <sup>-1</sup> | 7.86×10 <sup>-2</sup> |
| <b>NVT3105</b> | 8.55×10 <sup>-2</sup>  | 8.67×10 <sup>-2</sup> | 8.90×10 <sup>-2</sup> |
| <b>NVT3130</b> | 8.00×10 <sup>-2</sup>  | 7.57×10 <sup>-2</sup> | 1.16×10 <sup>-1</sup> |
| <b>NVT3155</b> | 5.56×10 <sup>-2</sup>  | 5.59×10 <sup>-2</sup> | 8.78×10 <sup>-2</sup> |
| <b>NVT3180</b> | 5.12×10 <sup>-2</sup>  | 5.08×10 <sup>-2</sup> | 9.25×10 <sup>-2</sup> |
| <b>NVT3205</b> | 4.76×10 <sup>-2</sup>  | 4.66×10 <sup>-2</sup> | 9.65×10 <sup>-2</sup> |
| <b>NVT3230</b> | 4.45×10 <sup>-2</sup>  | 4.31×10 <sup>-2</sup> | 9.99×10 <sup>-2</sup> |
| <b>NVT4085</b> | 1.01×10 <sup>-1</sup>  | 1.08×10 <sup>-1</sup> | 5.63×10 <sup>-2</sup> |
| <b>NVT4125</b> | 9.48×10 <sup>-2</sup>  | 8.81×10 <sup>-2</sup> | 8.72×10 <sup>-2</sup> |
| <b>NVT4165</b> | 6.01×10 <sup>-2</sup>  | 5.97×10 <sup>-2</sup> | 6.56×10 <sup>-2</sup> |
| <b>NVT4205</b> | 4.34×10 <sup>-2</sup>  | 4.39×10 <sup>-2</sup> | 6.03×10 <sup>-2</sup> |
| <b>NVT4245</b> | 4.06×10 <sup>-2</sup>  | 3.97×10 <sup>-2</sup> | 7.11×10 <sup>-2</sup> |
| <b>NVT4285</b> | 3.30×10 <sup>-2</sup>  | 3.28×10 <sup>-2</sup> | 6.38×10 <sup>-2</sup> |
| <b>NVT6110</b> | 1.74×10 <sup>-1</sup>  | 1.24×10 <sup>-1</sup> | 1.10×10 <sup>-1</sup> |
| <b>NVT6160</b> | 6.02×10 <sup>-2</sup>  | 6.08×10 <sup>-2</sup> | 5.66×10 <sup>-2</sup> |
| <b>NVT6210</b> | 4.82×10 <sup>-2</sup>  | 4.75×10 <sup>-2</sup> | 6.63×10 <sup>-2</sup> |
| <b>NVT6260</b> | 4.21×10 <sup>-2</sup>  | 4.06×10 <sup>-2</sup> | 6.85×10 <sup>-2</sup> |
| <b>NVT6310</b> | 2.95×10 <sup>-2</sup>  | 2.99×10 <sup>-2</sup> | 5.28×10 <sup>-2</sup> |
| <b>NVT6360</b> | 2.70×10 <sup>-2</sup>  | 2.70×10 <sup>-2</sup> | 5.53×10 <sup>-2</sup> |
| <b>NVT6410</b> | 2.53×10 <sup>-2</sup>  | 2.46×10 <sup>-2</sup> | 6.37×10 <sup>-2</sup> |

E<sub>P</sub>: Mp equivalent coefficient E<sub>Y</sub>: My equivalent coefficient  
E<sub>R</sub>: Mr equivalent coefficient

Table 1-21

Slide Table NVT type (2) unit: 1/mm

| part number    | equivalent coefficient |                       |                       |
|----------------|------------------------|-----------------------|-----------------------|
|                | E <sub>P</sub>         | E <sub>Y</sub>        | E <sub>R</sub>        |
| <b>NVT9210</b> | 7.51×10 <sup>-2</sup>  | 6.05×10 <sup>-2</sup> | 5.66×10 <sup>-2</sup> |
| <b>NVT9310</b> | 3.26×10 <sup>-2</sup>  | 3.25×10 <sup>-2</sup> | 4.00×10 <sup>-2</sup> |
| <b>NVT9410</b> | 2.36×10 <sup>-2</sup>  | 2.34×10 <sup>-2</sup> | 3.84×10 <sup>-2</sup> |
| <b>NVT9510</b> | 1.82×10 <sup>-2</sup>  | 1.83×10 <sup>-2</sup> | 3.34×10 <sup>-2</sup> |

E<sub>P</sub>: Mp equivalent coefficient E<sub>Y</sub>: My equivalent coefficient

E<sub>R</sub>: Mr equivalent coefficient

Table 1-23

Slide Table SVT type (1) unit: 1/mm

| part number    | equivalent coefficient |                       |                       |
|----------------|------------------------|-----------------------|-----------------------|
|                | E <sub>P</sub>         | E <sub>Y</sub>        | E <sub>R</sub>        |
| <b>SVT1025</b> | 2.67×10 <sup>-1</sup>  | 3.25×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT1035</b> | 3.10×10 <sup>-1</sup>  | 2.73×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT1045</b> | 1.71×10 <sup>-1</sup>  | 1.87×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT1055</b> | 1.51×10 <sup>-1</sup>  | 1.63×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT1065</b> | 1.35×10 <sup>-1</sup>  | 1.44×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT1075</b> | 1.11×10 <sup>-1</sup>  | 1.17×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT1085</b> | 1.02×10 <sup>-1</sup>  | 1.07×10 <sup>-1</sup> | 1.48×10 <sup>-1</sup> |
| <b>SVT2035</b> | 1.67×10 <sup>-1</sup>  | 2.03×10 <sup>-1</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2050</b> | 1.45×10 <sup>-1</sup>  | 1.64×10 <sup>-1</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2065</b> | 1.22×10 <sup>-1</sup>  | 1.37×10 <sup>-1</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2080</b> | 1.28×10 <sup>-1</sup>  | 1.19×10 <sup>-1</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2095</b> | 1.10×10 <sup>-1</sup>  | 1.03×10 <sup>-1</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2110</b> | 7.61×10 <sup>-2</sup>  | 8.08×10 <sup>-2</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2125</b> | 6.94×10 <sup>-2</sup>  | 7.33×10 <sup>-2</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2140</b> | 7.01×10 <sup>-2</sup>  | 6.73×10 <sup>-2</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2155</b> | 6.43×10 <sup>-2</sup>  | 6.19×10 <sup>-2</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2170</b> | 5.12×10 <sup>-2</sup>  | 5.33×10 <sup>-2</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT2185</b> | 4.81×10 <sup>-2</sup>  | 4.99×10 <sup>-2</sup> | 1.11×10 <sup>-1</sup> |
| <b>SVT3055</b> | 2.00×10 <sup>-1</sup>  | 1.75×10 <sup>-1</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3080</b> | 1.22×10 <sup>-1</sup>  | 1.12×10 <sup>-1</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3105</b> | 7.53×10 <sup>-2</sup>  | 8.14×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3130</b> | 6.08×10 <sup>-2</sup>  | 6.47×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3155</b> | 6.17×10 <sup>-2</sup>  | 5.89×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3180</b> | 5.15×10 <sup>-2</sup>  | 4.96×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3205</b> | 4.75×10 <sup>-2</sup>  | 4.59×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3230</b> | 3.85×10 <sup>-2</sup>  | 3.99×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3255</b> | 3.87×10 <sup>-2</sup>  | 3.76×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT3280</b> | 3.64×10 <sup>-2</sup>  | 3.54×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |

E<sub>P</sub>: Mp equivalent coefficient E<sub>Y</sub>: My equivalent coefficient

E<sub>R</sub>: Mr equivalent coefficient

Table 1-23

Slide Table SVT type (2) unit: 1/mm

| part number     | equivalent coefficient |                       |                       |
|-----------------|------------------------|-----------------------|-----------------------|
|                 | E <sub>P</sub>         | E <sub>Y</sub>        | E <sub>R</sub>        |
| <b>SVT3305</b>  | 3.09×10 <sup>-2</sup>  | 3.18×10 <sup>-2</sup> | 7.14×10 <sup>-2</sup> |
| <b>SVT4085</b>  | 8.29×10 <sup>-2</sup>  | 9.38×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4125</b>  | 6.11×10 <sup>-2</sup>  | 6.67×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4165</b>  | 6.27×10 <sup>-2</sup>  | 5.88×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4205</b>  | 4.89×10 <sup>-2</sup>  | 4.65×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4245</b>  | 4.01×10 <sup>-2</sup>  | 3.85×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4285</b>  | 3.39×10 <sup>-2</sup>  | 3.28×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4325</b>  | 2.94×10 <sup>-2</sup>  | 2.86×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4365</b>  | 2.60×10 <sup>-2</sup>  | 2.53×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT4405</b>  | 2.20×10 <sup>-2</sup>  | 2.27×10 <sup>-2</sup> | 5.00×10 <sup>-2</sup> |
| <b>SVT6110</b>  | 6.83×10 <sup>-2</sup>  | 7.72×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6160</b>  | 5.03×10 <sup>-2</sup>  | 5.49×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6210</b>  | 3.97×10 <sup>-2</sup>  | 4.24×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6260</b>  | 3.27×10 <sup>-2</sup>  | 3.45×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6310</b>  | 2.78×10 <sup>-2</sup>  | 2.90×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6360</b>  | 2.79×10 <sup>-2</sup>  | 2.70×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6410</b>  | 2.42×10 <sup>-2</sup>  | 2.35×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6460</b>  | 2.14×10 <sup>-2</sup>  | 2.08×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT6510</b>  | 1.92×10 <sup>-2</sup>  | 1.87×10 <sup>-2</sup> | 4.44×10 <sup>-2</sup> |
| <b>SVT9210</b>  | 3.50×10 <sup>-2</sup>  | 3.90×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9310</b>  | 3.14×10 <sup>-2</sup>  | 2.94×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9410</b>  | 2.41×10 <sup>-2</sup>  | 2.57×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9510</b>  | 1.98×10 <sup>-2</sup>  | 2.09×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9610</b>  | 2.00×10 <sup>-2</sup>  | 1.92×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9710</b>  | 1.70×10 <sup>-2</sup>  | 1.64×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9810</b>  | 1.37×10 <sup>-2</sup>  | 1.42×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT9910</b>  | 1.22×10 <sup>-2</sup>  | 1.26×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |
| <b>SVT91010</b> | 1.10×10 <sup>-2</sup>  | 1.13×10 <sup>-2</sup> | 2.78×10 <sup>-2</sup> |

E<sub>P</sub>: Mp equivalent coefficient E<sub>Y</sub>: My equivalent coefficient

E<sub>R</sub>: Mr equivalent coefficient

Table 1-24 Slide Table SYT type unit: 1/mm

| part number    | equivalent coefficient |                       |                       |
|----------------|------------------------|-----------------------|-----------------------|
|                | E <sub>P</sub>         | E <sub>Y</sub>        | E <sub>R</sub>        |
| <b>SYT1025</b> | 2.67×10 <sup>-1</sup>  | 3.25×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT1035</b> | 3.10×10 <sup>-1</sup>  | 2.73×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT1045</b> | 1.71×10 <sup>-1</sup>  | 1.87×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT1055</b> | 1.51×10 <sup>-1</sup>  | 1.63×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT1065</b> | 1.35×10 <sup>-1</sup>  | 1.44×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT1075</b> | 1.11×10 <sup>-1</sup>  | 1.17×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT1085</b> | 1.02×10 <sup>-1</sup>  | 1.07×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYT2035</b> | 1.67×10 <sup>-1</sup>  | 2.03×10 <sup>-1</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT2050</b> | 1.45×10 <sup>-1</sup>  | 1.64×10 <sup>-1</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT2065</b> | 1.22×10 <sup>-1</sup>  | 1.37×10 <sup>-1</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT2080</b> | 1.28×10 <sup>-1</sup>  | 1.19×10 <sup>-1</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT2095</b> | 1.10×10 <sup>-1</sup>  | 1.03×10 <sup>-1</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT2110</b> | 7.61×10 <sup>-2</sup>  | 8.08×10 <sup>-2</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT2125</b> | 6.94×10 <sup>-2</sup>  | 7.33×10 <sup>-2</sup> | 1.54×10 <sup>-1</sup> |
| <b>SYT3055</b> | 2.00×10 <sup>-1</sup>  | 1.75×10 <sup>-1</sup> | 1.15×10 <sup>-1</sup> |
| <b>SYT3080</b> | 1.22×10 <sup>-1</sup>  | 1.12×10 <sup>-1</sup> | 1.15×10 <sup>-1</sup> |
| <b>SYT3105</b> | 7.53×10 <sup>-2</sup>  | 8.14×10 <sup>-2</sup> | 1.15×10 <sup>-1</sup> |
| <b>SYT3130</b> | 6.08×10 <sup>-2</sup>  | 6.47×10 <sup>-2</sup> | 1.15×10 <sup>-1</sup> |
| <b>SYT3155</b> | 6.17×10 <sup>-2</sup>  | 5.89×10 <sup>-2</sup> | 1.15×10 <sup>-1</sup> |
| <b>SYT3180</b> | 5.15×10 <sup>-2</sup>  | 4.96×10 <sup>-2</sup> | 1.15×10 <sup>-1</sup> |
| <b>SYT3205</b> | 4.75×10 <sup>-2</sup>  | 4.59×10 <sup>-2</sup> | 1.15×10 <sup>-1</sup> |

E<sub>P</sub>: M<sub>P</sub> equivalent coefficient E<sub>Y</sub>: M<sub>Y</sub> equivalent coefficientE<sub>R</sub>: M<sub>R</sub> equivalent coefficient

Table 1-25 Miniature Slide SYBS type unit: 1/mm

| part number      | equivalent coefficient |                       |                       |
|------------------|------------------------|-----------------------|-----------------------|
|                  | E <sub>P</sub>         | E <sub>Y</sub>        | E <sub>R</sub>        |
| <b>SYBS 6-13</b> | 8.35×10 <sup>-1</sup>  | 7.01×10 <sup>-1</sup> | 8.51×10 <sup>-1</sup> |
| <b>SYBS 6-21</b> | 5.45×10 <sup>-1</sup>  | 4.57×10 <sup>-1</sup> | 8.51×10 <sup>-1</sup> |
| <b>SYBS 8-11</b> | 8.82×10 <sup>-1</sup>  | 7.40×10 <sup>-1</sup> | 5.88×10 <sup>-1</sup> |
| <b>SYBS 8-21</b> | 4.81×10 <sup>-1</sup>  | 4.04×10 <sup>-1</sup> | 5.88×10 <sup>-1</sup> |
| <b>SYBS 8-31</b> | 3.57×10 <sup>-1</sup>  | 2.99×10 <sup>-1</sup> | 5.88×10 <sup>-1</sup> |
| <b>SYBS12-23</b> | 4.31×10 <sup>-1</sup>  | 3.62×10 <sup>-1</sup> | 3.13×10 <sup>-1</sup> |
| <b>SYBS12-31</b> | 3.57×10 <sup>-1</sup>  | 2.99×10 <sup>-1</sup> | 3.13×10 <sup>-1</sup> |
| <b>SYBS12-46</b> | 2.35×10 <sup>-1</sup>  | 1.97×10 <sup>-1</sup> | 3.13×10 <sup>-1</sup> |
| <b>SYBS17-23</b> | 4.25×10 <sup>-1</sup>  | 3.57×10 <sup>-1</sup> | 2.67×10 <sup>-1</sup> |
| <b>SYBS17-31</b> | 3.26×10 <sup>-1</sup>  | 2.74×10 <sup>-1</sup> | 2.66×10 <sup>-1</sup> |
| <b>SYBS17-46</b> | 2.23×10 <sup>-1</sup>  | 1.88×10 <sup>-1</sup> | 2.66×10 <sup>-1</sup> |

E<sub>P</sub>: M<sub>P</sub> equivalent coefficient E<sub>Y</sub>: M<sub>Y</sub> equivalent coefficient  
E<sub>R</sub>: M<sub>R</sub> equivalent coefficient

### Average Applied Load

The load applied to a linear system generally varies with the travel distance depending on how the system is operated. This includes the start/stop processes of the reciprocating motion and work on the system. The average applied load is used to compute the life corresponding to the actual application conditions.

- ① When the load varies in a step manner with the travel distance (Figure 1-7).

 $\ell_1$  is the travel distance under load P<sub>1</sub> $\ell_2$  is the travel distance under load P<sub>2</sub>

⋮

 $\ell_n$  is the travel distance under load P<sub>n</sub>

The average applied load P<sub>m</sub> is obtained by the following equation.

$$P_m = \frac{1}{\ell} (P_1^3 \ell_1 + P_2^3 \ell_2 + \dots + P_n^3 \ell_n) \dots (10)$$

P<sub>m</sub>: average applied load (N)  $\ell$ : total travel distance (m)

Figure 1-7 Applied Load Varies Stepwise




Figure 1-8 Applied Load Varies Linearly





Figure 1-9 Applied Load Varies Sine-Curve



- ② When the applied load varies linearly with the travel distance (Figure 1-8), the average applied load P<sub>m</sub> is approximated by the following equation.

$$P_m = \frac{1}{3} (P_{min} + 2P_{max}) \dots (11)$$

P<sub>min</sub>: minimum applied load (N)P<sub>max</sub>: maximum applied load (N)

- ③ When the applied load draws a sine-curve as shown by Figures 1-9 (a) and (b), the average applied load P<sub>m</sub> is approximated by the following equations.

$$P_m = 0.65P_{max} \dots (12)$$

$$P_m = 0.75P_{max} \dots (13)$$

## RATED LIFE CALCULATION EXAMPLE 1

## 2 Horizontal Axes, 2 Blocks each, Considering Acceleration/Deceleration

## Operating Conditions

part number: SGL15F/E

basic dynamic load rating  $C=7.29\text{kN}$ basic static load rating  $C_0=9.45\text{kN}$ guide block span:  $L_{unit}=100\text{mm}$ guide rail span:  $L_{rail}=100\text{mm}$ drive:  $Y_d=10\text{mm}$  $Z_d=-10\text{mm}$ mass:  $m_1=30\text{kg}$   $X_1=15\text{mm}$  $Y_1=-20\text{mm}$  $Z_1=20\text{mm}$ mass:  $m_2=15\text{kg}$   $X_2=80\text{mm}$  $Y_2=50\text{mm}$  $Z_2=100\text{mm}$ velocity:  $V_{max}=200\text{mm/s}$ time:  $t_1=0.2\text{s}$  $t_2=3.3\text{s}$  $t_3=0.2\text{s}$ acceleration:  $a_1=1.0\text{m/s}^2$  $a_3=1.0\text{m/s}^2$ stroke:  $\ell_s=700\text{mm}$ number of cycles per minute:  $n_l=8\text{cpm}$ 

Figure 1-10






Figure 1-11



In case that some external force is applied to the system, please refer to "Slide Guide Travel Life Calculation Program" at NB website.

## ① Calculating Moment Applied to the Unit

## &lt;acceleration&gt;

$$\text{pitching } Ma_1 = m \cdot g \cdot X_m - m \cdot a_1 \cdot (Z_m - Z_d)$$

$$Ma_1 = 30 \times 9.8 \times (15) - 30 \times 1 \times \{(20) - (-10)\} + 15 \times 9.8 \times (80) - 15 \times 1 \times \{(100) - (-10)\} = 13620\text{N}\cdot\text{mm}$$

$$\text{yawing } Ma_2 = -m \cdot a_1 \cdot (Y_m - Y_d)$$

$$Ma_2 = -30 \times 1 \times \{(-20) - (10)\} - 15 \times 1 \times \{(50) - (10)\} = 300\text{N}\cdot\text{mm}$$

$$\text{rolling } Ma_3 = m \cdot g \cdot Y_m$$

$$Ma_3 = 30 \times 9.8 \times (-20) + 15 \times 9.8 \times (50) = 1470\text{N}\cdot\text{mm}$$

## &lt;constant&gt;

$$\text{pitching } M_1 = m \cdot g \cdot X_m$$

$$M_1 = 30 \times 9.8 \times (15) + 15 \times 9.8 \times (80) = 16170\text{N}\cdot\text{mm}$$

$$\text{yawing } M_2 = 0$$

$$\text{rolling } M_3 = m \cdot g \cdot Y_m$$

$$M_3 = 30 \times 9.8 \times (-20) + 15 \times 9.8 \times (50) = 1470\text{N}\cdot\text{mm}$$

## &lt;deceleration&gt;

$$\text{pitching } Md_1 = m \cdot g \cdot X_m + m \cdot a_3 \cdot (Z_m - Z_d)$$

$$Md_1 = 30 \times 9.8 \times (15) + 30 \times 1 \times \{(20) - (-10)\} + 15 \times 9.8 \times (80) + 15 \times 1 \times \{(100) - (-10)\} = 18720\text{N}\cdot\text{mm}$$

$$\text{yawing } Md_2 = m \cdot a_3 \cdot (Y_m - Y_d)$$

$$Md_2 = 30 \times 1 \times \{(-20) - (10)\} + 15 \times 1 \times \{(50) - (10)\} = -300\text{N}\cdot\text{mm}$$

$$\text{rolling } Md_3 = m \cdot g \cdot Y_m$$

$$Md_3 = 30 \times 9.8 \times (-20) + 15 \times 9.8 \times (50) = 1470\text{N}\cdot\text{mm}$$

## ② Calculating Load Applied to the Guide Block

## &lt;acceleration&gt;

$$\text{Block 1} \quad \text{vertical direction } F_{ra1} = \frac{m \cdot g}{4} - \frac{Ma_1}{2 \cdot L_{unit}} + \frac{Ma_3}{2 \cdot L_{rail}}$$

$$F_{ra1} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} - \frac{13620}{2 \times 100} + \frac{1470}{2 \times 100} = 49.5\text{N}$$

$$\text{horizontal direction } F_{sa1} = \frac{Ma_2}{2 \cdot L_{unit}}$$

$$F_{sa1} = \frac{300}{2 \times 100} = 1.5\text{N}$$

$$\text{Block 2} \quad \text{vertical direction } F_{ra2} = \frac{m \cdot g}{4} + \frac{Ma_1}{2 \cdot L_{unit}} + \frac{Ma_3}{2 \cdot L_{rail}}$$

$$F_{ra2} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} + \frac{13620}{2 \times 100} + \frac{1470}{2 \times 100} = 185.7\text{N}$$

$$\text{horizontal direction } F_{sa2} = -\frac{Ma_2}{2 \cdot L_{unit}}$$

$$F_{sa2} = -\frac{300}{2 \times 100} = -1.5\text{N}$$

Block 3

vertical direction  $F_{ra3} = \frac{m \cdot g}{4} - \frac{Ma_1}{2 \cdot L_{unit}} - \frac{Ma_3}{2 \cdot L_{rail}}$

 $F_{ra3} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} - \frac{13620}{2 \times 100} - \frac{1470}{2 \times 100} = 34.8N$ 

horizontal direction  $F_{sa3} = \frac{Ma_2}{2 \cdot L_{unit}}$

 $F_{sa3} = \frac{300}{2 \times 100} = 1.5N$

Block 4

vertical direction  $F_{ra4} = \frac{m \cdot g}{4} + \frac{Ma_1}{2 \cdot L_{unit}} - \frac{Ma_3}{2 \cdot L_{rail}}$

 $F_{ra4} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} + \frac{13620}{2 \times 100} - \frac{1470}{2 \times 100} = 171.0N$ 

horizontal direction  $F_{sa4} = -\frac{Ma_2}{2 \cdot L_{unit}}$

 $F_{sa4} = -\frac{300}{2 \times 100} = -1.5N$

(constant)

Block 1 vertical direction  $Fr_1 = \frac{m \cdot g}{4} - \frac{M_1}{2 \cdot L_{unit}} + \frac{M_3}{2 \cdot L_{rail}}$

 $Fr_1 = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} - \frac{16170}{2 \times 100} + \frac{1470}{2 \times 100} = 36.8N$ 

horizontal direction  $Fs_1 = \frac{M_2}{2 \cdot L_{unit}}$

Block 2

vertical direction  $Fr_2 = \frac{m \cdot g}{4} + \frac{M_1}{2 \cdot L_{unit}} + \frac{M_3}{2 \cdot L_{rail}}$

 $Fr_2 = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} + \frac{16170}{2 \times 100} + \frac{1470}{2 \times 100} = 198.5N$ 

horizontal direction  $Fs_2 = -\frac{M_2}{2 \cdot L_{unit}}$

Block 3

vertical direction  $Fr_3 = \frac{m \cdot g}{4} - \frac{M_1}{2 \cdot L_{unit}} - \frac{M_3}{2 \cdot L_{rail}}$

 $Fr_3 = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} - \frac{16170}{2 \times 100} - \frac{1470}{2 \times 100} = 22.1N$ 

horizontal direction  $Fs_3 = \frac{M_2}{2 \cdot L_{unit}}$

Block 4

vertical direction  $Fr_4 = \frac{m \cdot g}{4} + \frac{M_1}{2 \cdot L_{unit}} - \frac{M_3}{2 \cdot L_{rail}}$

 $Fr_4 = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} + \frac{16170}{2 \times 100} - \frac{1470}{2 \times 100} = 183.8N$ 

horizontal direction  $Fs_4 = -\frac{M_2}{2 \cdot L_{unit}}$

(deceleration)

Block 1 vertical direction  $Fr_{d1} = \frac{m \cdot g}{4} - \frac{Md_1}{2 \cdot L_{unit}} + \frac{Md_3}{2 \cdot L_{rail}}$

 $Fr_{d1} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} - \frac{18720}{2 \times 100} + \frac{1470}{2 \times 100} = 24.0N$ 

horizontal direction  $Fs_{d1} = \frac{Md_2}{2 \cdot L_{unit}}$

 $Fs_{d1} = \frac{-300}{2 \times 100} = -1.5N$

Block 2

vertical direction  $Fr_{d2} = \frac{m \cdot g}{4} + \frac{Md_1}{2 \cdot L_{unit}} + \frac{Md_3}{2 \cdot L_{rail}}$

 $Fr_{d2} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} + \frac{18720}{2 \times 100} + \frac{1470}{2 \times 100} = 211.2N$ 

horizontal direction  $Fs_{d2} = -\frac{Md_2}{2 \cdot L_{unit}}$

 $Fs_{d2} = -\frac{-300}{2 \times 100} = 1.5N$

Block 3

vertical direction  $Fr_{d3} = \frac{m \cdot g}{4} - \frac{Md_1}{2 \cdot L_{unit}} - \frac{Md_3}{2 \cdot L_{rail}}$

 $Fr_{d3} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} - \frac{18720}{2 \times 100} - \frac{1470}{2 \times 100} = 9.3N$ 

horizontal direction  $Fs_{d3} = \frac{Md_2}{2 \cdot L_{unit}}$

 $Fs_{d3} = \frac{-300}{2 \times 100} = -1.5N$

Block 4

vertical direction  $Fr_{d4} = \frac{m \cdot g}{4} + \frac{Md_1}{2 \cdot L_{unit}} - \frac{Md_3}{2 \cdot L_{rail}}$

 $Fr_{d4} = \frac{30 \times 9.8}{4} + \frac{15 \times 9.8}{4} + \frac{18720}{2 \times 100} - \frac{1470}{2 \times 100} = 196.5N$ 

horizontal direction  $Fs_{d4} = -\frac{Md_2}{2 \cdot L_{unit}}$

 $Fs_{d4} = -\frac{-300}{2 \times 100} = 1.5N$

### ③ Calculating Equivalent Load

○ Pr in the vertical direction and Ps in the horizontal direction are calculated by the following equations.

$$Pr = |Fr|$$

$$Ps = |k \cdot Fs|$$

k=1 for SGL guide

Table 1-26

|         | acceleration | constant  | deceleration |
|---------|--------------|-----------|--------------|
| block 1 | Pra1=49.5    | Pr1=36.8  | Prd1=24.0    |
|         | Psa1=1.5     | Ps1=0     | Psd1=1.5     |
| block 2 | Pra2=185.7   | Pr2=198.5 | Prd2=211.2   |
|         | Psa2=1.5     | Ps2=0     | Psd2=1.5     |
| block 3 | Pra3=34.8    | Pr3=22.1  | Prd3=9.3     |
|         | Psa3=1.5     | Ps3=0     | Psd3=1.5     |
| block 4 | Pra4=171.0   | Pr4=183.8 | Prd4=196.5   |
|         | Psa4=1.5     | Ps4=0     | Psd4=1.5     |

## ◎Equation for Dynamic Equivalent Load

$$P = P_{r1} + P_{s1}$$

$$P_{a1} = P_{ra1} + P_{sa1} = 49.5 + 1.5 = 51.0 \text{ (N)}$$

calculating in the same manner

Table 1-27

|         | acceleration           | constant              | deceleration           |
|---------|------------------------|-----------------------|------------------------|
| block 1 | P <sub>a1</sub> =51.0  | P <sub>1</sub> =36.8  | P <sub>d1</sub> =25.5  |
| block 2 | P <sub>a2</sub> =187.2 | P <sub>2</sub> =198.5 | P <sub>d2</sub> =212.7 |
| block 3 | P <sub>a3</sub> =36.3  | P <sub>3</sub> =22.1  | P <sub>d3</sub> =10.8  |
| block 4 | P <sub>a4</sub> =172.5 | P <sub>4</sub> =183.8 | P <sub>d4</sub> =198.0 |

## ◎Calculating Average Equivalent Load

$$P_m = \sqrt[3]{\frac{1}{\ell_s} \times \left( (P_{a1}^3 \times \frac{V_{max} \times t1}{2}) + (P_1^3 \times V_{max} \times t2) + (P_{d1}^3 \times \frac{V_{max} \times t3}{2}) \right)}$$

$$P_{m1} = \sqrt[3]{\frac{1}{700} \times \left( (51.0^3 \times \frac{200 \times 0.2}{2}) + (36.8^3 \times 200 \times 3.3) + (25.5^3 \times \frac{200 \times 0.2}{2}) \right)} = 37.1 \text{ (N)}$$

$$P_{m2} = \sqrt[3]{\frac{1}{700} \times \left( (187.2^3 \times \frac{200 \times 0.2}{2}) + (198.5^3 \times 200 \times 3.3) + (212.7^3 \times \frac{200 \times 0.2}{2}) \right)} = 198.6 \text{ (N)}$$

$$P_{m3} = \sqrt[3]{\frac{1}{700} \times \left( (36.3^3 \times \frac{200 \times 0.2}{2}) + (22.1^3 \times 200 \times 3.3) + (10.8^3 \times \frac{200 \times 0.2}{2}) \right)} = 22.6 \text{ (N)}$$

$$P_{m4} = \sqrt[3]{\frac{1}{700} \times \left( (172.5^3 \times \frac{200 \times 0.2}{2}) + (183.8^3 \times 200 \times 3.3) + (198.0^3 \times \frac{200 \times 0.2}{2}) \right)} = 183.9 \text{ (N)}$$

## ④ Calculating Rated Life

Decide each coefficient

f<sub>H</sub> : hardness coefficient f<sub>H</sub>=1 for hardness of guide is 58HRC or more

f<sub>T</sub> : temperature coefficient f<sub>T</sub>=1 operating temperature is below 100°C (80°C is maximum for SGL guide)

f<sub>C</sub> : contact coefficient f<sub>C</sub>=1 for blocks are not in close contact

f<sub>w</sub> : applied load coefficient f<sub>w</sub>=1.5 for V<sub>max</sub>=200mm/s

## ◎Calculating Rated Life

Selecting Block 2 that carries the maximum dynamic equivalent load

$$L = \left( \frac{f_H \times f_T \times f_C}{f_w} \times \frac{C}{P_m} \right)^3 \times 50$$

$$L = \left( \frac{1 \times 1 \times 1}{1.5} \times \frac{7290}{198.6} \right)^3 \times 50 = 732725 \text{ (km)}$$

## ◎Calculating Life Time

$$L_h = \frac{L \times 10^3}{2 \times \ell_s \times n_1 \times 60}$$

$$L_h = \frac{732725 \times 10^3}{2 \times 0.7 \times 8 \times 60} = 1090364 \text{ (hour)}$$

## ⑤ Calculating Static Safety Factor

## ◎Equation for Static Equivalent Load

$$P_o = P_{r1} + P_{s1}$$

$$P_{o1} = P_{ra1} + P_{sa1} = 49.5 + 1.5 = 51.0 \text{ (N)}$$

calculating in the same manner

Table 1-28

|         | acceleration           | constant               | deceleration            |
|---------|------------------------|------------------------|-------------------------|
| block 1 | P <sub>o1</sub> =51.0  | P <sub>o1</sub> =36.8  | P <sub>od1</sub> =25.5  |
| block 2 | P <sub>o2</sub> =187.2 | P <sub>o2</sub> =198.5 | P <sub>od2</sub> =212.7 |
| block 3 | P <sub>o3</sub> =36.3  | P <sub>o3</sub> =22.1  | P <sub>od3</sub> =10.8  |
| block 4 | P <sub>o4</sub> =172.5 | P <sub>o4</sub> =183.8 | P <sub>od4</sub> =198.0 |

Selecting Block 2 that carries the maximum static equivalent load

$$f_s = \frac{C_o}{P_o}$$

$$f_s = \frac{C_o}{P_{od2}} = \frac{9450}{212.7} = 44$$

## RATED LIFE CALCULATION EXAMPLE 2

## 1 Horizontal Axis, 2 Blocks, Considering Acceleration/Deceleration

## Operating Conditions

part number: SEB9A

basic dynamic load rating  $C=1.92\text{kN}$ basic static load rating  $C_0=2.53\text{kN}$ guide block span:  $L_{\text{unit}}=70\text{mm}$ drive:  $Y_d=30\text{mm}$  $Z_d=-10\text{mm}$ mass:  $m_1=5\text{kg}$      $X_1=0\text{mm}$  $Y_1=0\text{mm}$  $Z_1=10\text{mm}$  $m_2=20\text{kg}$      $X_2=-20\text{mm}$  $Y_2=-10\text{mm}$  $Z_2=20\text{mm}$ velocity:  $V_{\text{max}}=150\text{mm/s}$ time:  $t_1=0.1\text{s}$  $t_2=1.9\text{s}$  $t_3=0.1\text{s}$ acceleration:  $a_1=1.5\text{m/s}^2$  $a_3=1.5\text{m/s}^2$ stroke:  $\ell_s=300\text{mm}$ number of cycles per minute:  $n_1=14\text{cpm}$ 

Figure 1-12





Figure 1-13



## ① Calculating Moment Applied to the Unit

## &lt;acceleration&gt;

pitching  $M_{a1}=m \cdot g \cdot X_m - m \cdot a_1 \cdot (Z_m - Z_d)$

$M_{a1}=5 \times 9.8 \times (0) - 5 \times 1.5 \times \{(10) - (-10)\} + 20 \times 9.8 \times (-20) - 20 \times 1.5 \times \{(20) - (-10)\} = -4970\text{N}\cdot\text{mm}$

yawing  $M_{a2}=-m \cdot a_1 \cdot (Y_m - Y_d)$

$M_{a2}=-5 \times 1.5 \times \{(0) - (-30)\} - 20 \times 1.5 \times \{(-10) - (-30)\} = -825\text{N}\cdot\text{mm}$

rolling  $M_{a3}=m \cdot g \cdot Y_m$

$M_{a3}=5 \times 9.8 \times (0) + 20 \times 9.8 \times (-10) = -1960\text{N}\cdot\text{mm}$

## &lt;constant&gt;

pitching  $M_1=m \cdot g \cdot X_m$

$M_1=5 \times 9.8 \times (0) + 20 \times 9.8 \times (-20) = -3920\text{N}\cdot\text{mm}$

yawing  $M_2=0$

$M_2=0\text{ N}\cdot\text{mm}$

rolling  $M_3=m \cdot g \cdot Y_m$

$M_3=5 \times 9.8 \times (0) + 20 \times 9.8 \times (-10) = -1960\text{N}\cdot\text{mm}$

## &lt;deceleration&gt;

pitching  $M_{d1}=m \cdot g \cdot X_m + m \cdot a_3 \cdot (Z_m - Z_d)$

$M_{d1}=5 \times 9.8 \times (0) + 5 \times 1.5 \times \{(10) - (-10)\} + 20 \times 9.8 \times (-20) + 20 \times 1.5 \times \{(20) - (-10)\} = -2870\text{N}\cdot\text{mm}$

yawing  $M_{d2}=m \cdot a_3 \cdot (Y_m - Y_d)$

$M_{d2}=5 \times 1.5 \times \{(0) - (-30)\} + 20 \times 1.5 \times \{(-10) - (-30)\} = 825\text{N}\cdot\text{mm}$

rolling  $M_{d3}=m \cdot g \cdot Y_m$

$M_{d3}=5 \times 9.8 \times (0) + 20 \times 9.8 \times (-10) = -1960\text{N}\cdot\text{mm}$

## ② Calculating Load Applied to the Guide Block

〈acceleration〉

Block 1 vertical direction  $F_{ra1} = \frac{m \cdot g}{2} - \frac{Ma_1}{L_{unit}}$   
 $F_{ra1} = \frac{5 \times 9.8}{2} + \frac{20 \times 9.8}{2} - \frac{-4970}{70} = 193.5N$

horizontal direction  $F_{sa1} = \frac{Ma_2}{L_{unit}}$   
 $F_{sa1} = \frac{-825}{70} = -11.8N$

rolling moment  $M_{ra1} = \frac{Ma_3}{2}$   
 $M_{ra1} = \frac{-1960}{2} = -980N \cdot mm$

Block 2 vertical direction  $F_{ra2} = \frac{m \cdot g}{2} + \frac{Ma_1}{L_{unit}}$   
 $F_{ra2} = \frac{5 \times 9.8}{2} + \frac{20 \times 9.8}{2} + \frac{-4970}{70} = 51.5N$

horizontal direction  $F_{sa2} = \frac{Ma_2}{L_{unit}}$   
 $F_{sa2} = \frac{-825}{70} = -11.8N$

rolling moment  $M_{ra2} = \frac{Ma_3}{2}$   
 $M_{ra2} = \frac{-1960}{2} = -980N \cdot mm$

〈constant〉

Block 1 vertical direction  $F_{r1} = \frac{m \cdot g}{2} - \frac{M_1}{L_{unit}}$   
 $F_{r1} = \frac{5 \times 9.8}{2} + \frac{20 \times 9.8}{2} - \frac{-3920}{70} = 178.5N$

horizontal direction  $F_{s1} = \frac{M_2}{L_{unit}}$

rolling moment  $M_{r1} = \frac{M_3}{2}$

$M_{r1} = \frac{-1960}{2} = -980N \cdot mm$

Block 2 vertical direction  $F_{r2} = \frac{m \cdot g}{2} + \frac{M_1}{L_{unit}}$   
 $F_{r2} = \frac{5 \times 9.8}{2} + \frac{20 \times 9.8}{2} + \frac{-3920}{70} = 66.5N$

horizontal direction  $F_{s2} = -\frac{M_2}{L_{unit}}$

rolling moment  $M_{r2} = \frac{M_3}{2}$

$M_{r2} = \frac{-1960}{2} = -980N \cdot mm$

〈deceleration〉

Block 1 vertical direction  $F_{rd1} = \frac{m \cdot g}{2} - \frac{Md_1}{L_{unit}}$   
 $F_{rd1} = \frac{5 \times 9.8}{2} + \frac{20 \times 9.8}{2} - \frac{-2870}{70} = 163.5N$

horizontal direction  $F_{sd1} = \frac{Md_2}{L_{unit}}$   
 $F_{sd1} = \frac{825}{70} = 11.8N$

rolling moment  $M_{rd1} = \frac{Md_3}{2}$   
 $M_{rd1} = \frac{-1960}{2} = -980N \cdot mm$

Block 2 vertical direction  $F_{rd2} = \frac{m \cdot g}{2} + \frac{Md_1}{L_{unit}}$   
 $F_{rd2} = \frac{5 \times 9.8}{2} + \frac{20 \times 9.8}{2} + \frac{-2870}{70} = 81.5N$

horizontal direction  $F_{sd2} = -\frac{Md_2}{L_{unit}}$   
 $F_{sd2} = -\frac{825}{70} = -11.8N$

rolling moment  $M_{rd2} = \frac{Md_3}{2}$   
 $M_{rd2} = \frac{-1960}{2} = -980N \cdot mm$

### ③ Calculating Equivalent Load

◎ Pr in the vertical direction and Ps in the horizontal direction are calculated by the following equations.

$$Pr = |Fr| + |Er \cdot Mr|$$

$$Ps = |k \cdot Fs|$$

Er=0.220 for SEB9A

k=0.84 for SEB-A guide

$$Pra_1 = |Fr_{a1}| + |Er \cdot Mr_{a1}| = |193.5| + |0.220 \times (-980)| = 409.1 \text{ (N)}$$

calculating in the same manner

Table 1-29

|         | acceleration            | constant               | deceleration            |
|---------|-------------------------|------------------------|-------------------------|
| block 1 | Pra <sub>1</sub> =409.1 | Pr <sub>1</sub> =394.1 | Prd <sub>1</sub> =379.1 |
|         | Psa <sub>1</sub> =9.9   | Ps <sub>1</sub> =0     | Psd <sub>1</sub> =9.9   |
| block 2 | Pra <sub>2</sub> =267.1 | Pr <sub>2</sub> =282.1 | Prd <sub>2</sub> =297.1 |
|         | Psa <sub>2</sub> =9.9   | Ps <sub>2</sub> =0     | Psd <sub>2</sub> =9.9   |

◎ Equation for Dynamic Equivalent Load

$$P=Pr+Ps$$

$$Pa_1=Pr_{a1}+Ps_{a1}=409.1+9.9=419.0 \text{ (N)}$$

calculating in the same manner

Table 1-30

|         | acceleration           | constant              | deceleration           |
|---------|------------------------|-----------------------|------------------------|
| block 1 | Pa <sub>1</sub> =419.0 | P <sub>1</sub> =394.1 | Pd <sub>1</sub> =389.0 |
| block 2 | Pa <sub>2</sub> =277.0 | P <sub>2</sub> =282.1 | Pd <sub>2</sub> =307.0 |

◎ Calculating Average Equivalent Load

$$Pm=\sqrt[3]{\frac{1}{ls} \times \left( Pa^3 \times \frac{V_{max} \times t_1}{2} + (P^3 \times V_{max} \times t_2) + (Pd^3 \times \frac{V_{max} \times t_3}{2}) \right)}$$

$$Pm_1=\sqrt[3]{\frac{1}{300} \times \left( 419.0^3 \times \frac{150 \times 0.1}{2} + (394.1^3 \times 150 \times 1.9) + (389.0^3 \times \frac{150 \times 0.1}{2}) \right)}=394.6 \text{ (N)}$$

$$Pm_2=\sqrt[3]{\frac{1}{300} \times \left( 277.0^3 \times \frac{150 \times 0.1}{2} + (282.1^3 \times 150 \times 1.9) + (307.0^3 \times \frac{150 \times 0.1}{2}) \right)}=282.7 \text{ (N)}$$

### ④ Calculating Rated Life

Decide each coefficient

f<sub>H</sub>: hardness coefficient f<sub>H</sub>=1 for hardness of guide is 58HRC or more

f<sub>T</sub>: temperature coefficient f<sub>T</sub>=1 operating temperature is below 100°C  
(80°C is maximum for SEB-A guide)

f<sub>C</sub>: contact coefficient f<sub>C</sub>=1 for blocks are not in close contact

f<sub>w</sub>: applied load coefficient f<sub>w</sub>=1.5 for V<sub>max</sub>=150mm/s

#### ◎ Calculating Rated Life

Selecting Block 1 that carries the maximum dynamic equivalent load

$$L=\left(\frac{f_H \times f_T \times f_C}{f_w} \times \frac{C}{Pm}\right)^3 \times 50$$

$$L=\left(\frac{1 \times 1 \times 1}{1.5} \times \frac{1920}{394.6}\right)^3 \times 50=1706 \text{ (km)}$$

#### ◎ Calculating Life Time

$$L_h=\frac{L \times 10^3}{2 \times ls \times n_1 \times 60}$$

$$L_h=\frac{1706 \times 10^3}{2 \times 0.3 \times 14 \times 60}=3384 \text{ (hour)}$$

### ⑤ Calculating Static Safety Factor

◎ Equation for Static Equivalent Load

$$Po=Pr+Ps$$

$$Po_{a1}=Pr_{a1}+Ps_{a1}=409.1+9.9=419.0 \text{ (N)}$$

calculating in the same manner

Table 1-31

|         | acceleration           | constant              | deceleration           |
|---------|------------------------|-----------------------|------------------------|
| block 1 | Po <sub>1</sub> =419.0 | P <sub>1</sub> =394.1 | Pd <sub>1</sub> =389.0 |
| block 2 | Po <sub>2</sub> =277.0 | P <sub>2</sub> =282.1 | Pd <sub>2</sub> =307.0 |

Selecting Block 1 that carries the maximum static equivalent load

$$fs=\frac{Co}{Po}$$

$$fs=\frac{Co}{Po_{a1}}=\frac{2530}{419.0}=6.0$$

## RATED LIFE CALCULATION EXAMPLE 3

## 2 Vertical Axes, 1 Bush each, Considering Acceleration/Deceleration

## Operating Conditions

part number: SM30W

basic dynamic load rating  $C=2.49\text{kN}$ basic static load rating  $C_0=5.49\text{kN}$ shaft span:  $L_{\text{rail}}=80\text{mm}$ drive:  $Y_d=20\text{mm}$  $Z_d=-20\text{mm}$ mass:  $m_1=5\text{kg}$      $X_1=0\text{mm}$  $Y_1=0\text{mm}$  $Z_1=30\text{mm}$  $m_2=20\text{kg}$      $X_2=40\text{mm}$  $Y_2=50\text{mm}$  $Z_2=20\text{mm}$ velocity:  $V_{\text{max}}=150\text{mm/s}$ time:  $t_1=0.1\text{s}$  $t_2=0.7\text{s}$  $t_3=0.1\text{s}$ acceleration:  $a_1=1.5\text{m/s}^2$  $a_3=1.5\text{m/s}^2$ stroke:  $\ell_s=120\text{mm}$ number of cycles per minute:  $n=33\text{cpm}$ 

Figure 1-14





Figure 1-15



## ① Calculating Moment Applied to the Unit

## &lt;acceleration&gt;

pitching  $M_{a1}=m \cdot g \cdot (Z_m - Z_d) + m \cdot a_1 \cdot (Z_m - Z_d)$

$M_{a1}=5 \times 9.8 \times \{(30) - (-20)\} + 5 \times 1.5 \times \{(30) - (-20)\} + 20 \times 9.8 \times \{(20) - (-20)\} + 20 \times 1.5 \times \{(20) - (-20)\} = 11865\text{N}\cdot\text{mm}$

yawing  $M_{a2}=m \cdot g \cdot (Y_m - Y_d) + m \cdot a_1 \cdot (Y_m - Y_d)$

$M_{a2}=5 \times 9.8 \times \{(0) - (20)\} + 5 \times 1.5 \times \{(0) - (20)\} + 20 \times 9.8 \times \{(50) - (20)\} + 20 \times 1.5 \times \{(50) - (20)\} = 5650\text{N}\cdot\text{mm}$

rolling  $M_{a3}=0$

## &lt;constant&gt;

pitching  $M_1=m \cdot g \cdot (Z_m - Z_d)$

$M_1=5 \times 9.8 \times \{(30) - (-20)\} + 20 \times 9.8 \times \{(20) - (-20)\} = 10290\text{N}\cdot\text{mm}$

yawing  $M_2=m \cdot g \cdot (Y_m - Y_d)$

$M_2=5 \times 9.8 \times \{(0) - (20)\} + 20 \times 9.8 \times \{(50) - (20)\} = 4900\text{N}\cdot\text{mm}$

rolling  $M_3=0$

## &lt;deceleration&gt;

pitching  $M_{d1}=m \cdot g \cdot (Z_m - Z_d) - m \cdot a_3 \cdot (Z_m - Z_d)$

$M_{d1}=5 \times 9.8 \times \{(30) - (-20)\} - 5 \times 1.5 \times \{(30) - (-20)\} + 20 \times 9.8 \times \{(20) - (-20)\} - 20 \times 1.5 \times \{(20) - (-20)\} = 8715\text{N}\cdot\text{mm}$

yawing  $M_{d2}=m \cdot g \cdot (Y_m - Y_d) - m \cdot a_3 \cdot (Y_m - Y_d)$

$M_{d2}=5 \times 9.8 \times \{(0) - (20)\} - 5 \times 1.5 \times \{(0) - (20)\} + 20 \times 9.8 \times \{(50) - (20)\} - 20 \times 1.5 \times \{(50) - (20)\} = 4150\text{N}\cdot\text{mm}$

rolling  $M_{d3}=0$

## ② Calculating Load Applied to the Slide Bush

## &lt;acceleration&gt;

Bush 1    vertical direction  $F_{ra1}=\frac{M_{a3}}{L_{\text{rail}}}=0$

horizontal direction  $F_{sa1}=0$

pitching  $M_{pa1}=\frac{M_{a1}}{2}$

$M_{pa1}=\frac{11865}{2}=5932.5\text{N}\cdot\text{mm}$

yawing  $M_{ya1}=\frac{M_{a2}}{2}$

$M_{ya1}=\frac{5650}{2}=2825\text{N}\cdot\text{mm}$

Bush 2

vertical direction  $F_{ra2} = \frac{Ma_3}{L_{rail}} = 0$

horizontal direction  $F_{sa2} = 0$

pitching  $M_{pa2} = \frac{Ma_1}{2}$

$$M_{pa2} = \frac{11865}{2} = 5932.5 \text{ N} \cdot \text{mm}$$

yawing  $M_{ya2} = \frac{Ma_2}{2}$

$$M_{ya2} = \frac{5650}{2} = 2825 \text{ N} \cdot \text{mm}$$

{constant}

Bush 1

vertical direction  $F_{r1} = \frac{M_3}{L_{rail}} = 0$

horizontal direction  $F_{s1} = 0$

pitching  $M_{p1} = \frac{M_1}{2}$

$$M_{p1} = \frac{10290}{2} = 5145 \text{ N} \cdot \text{mm}$$

yawing  $M_{y1} = \frac{M_2}{2}$

$$M_{y1} = \frac{4900}{2} = 2450 \text{ N} \cdot \text{mm}$$

Bush 2

vertical direction  $F_{r2} = \frac{M_3}{L_{rail}} = 0$

horizontal direction  $F_{s2} = 0$

pitching  $M_{p2} = \frac{M_1}{2}$

$$M_{p2} = \frac{10290}{2} = 5145 \text{ N} \cdot \text{mm}$$

yawing  $M_{y2} = \frac{M_2}{2}$

$$M_{y2} = \frac{4900}{2} = 2450 \text{ N} \cdot \text{mm}$$

{deceleration}

Bush 1

vertical direction  $F_{rd1} = \frac{Md_3}{L_{rail}} = 0$

horizontal direction  $F_{sd1} = 0$

pitching  $M_{pd1} = \frac{Md_1}{2}$

$$M_{pd1} = \frac{8715}{2} = 4357.5 \text{ N} \cdot \text{mm}$$

yawing  $M_{yd1} = \frac{Md_2}{2}$

$$M_{yd1} = \frac{4150}{2} = 2075 \text{ N} \cdot \text{mm}$$

Bush 2

vertical direction  $F_{rd2} = \frac{Md_3}{L_{rail}} = 0$

horizontal direction  $F_{sd2} = 0$

pitching  $M_{pd2} = \frac{Md_1}{2}$

$$M_{pd2} = \frac{8715}{2} = 4357.5 \text{ N} \cdot \text{mm}$$

yawing  $M_{yd2} = \frac{Md_2}{2}$

$$M_{yd2} = \frac{4150}{2} = 2075 \text{ N} \cdot \text{mm}$$

### ③ Calculating Equivalent Load

◎ Pr in the vertical direction and Ps in the horizontal direction are calculated by the following equations.

$$Pr = |Fr| + |E_1 \cdot Mp|$$

$$Ps = |k \cdot Fs| + |E_1 \cdot My|$$

$$E_1 = 6.63 \times 10^{-2} \text{ for SM30W}$$

k=1 for Slide Bush

Table 1-32

|        | acceleration            | constant               | deceleration            |
|--------|-------------------------|------------------------|-------------------------|
| bush 1 | Pra <sub>1</sub> =393.3 | Pr <sub>1</sub> =341.1 | Prd <sub>1</sub> =288.9 |
|        | Psa <sub>1</sub> =187.3 | Ps <sub>1</sub> =162.4 | Psd <sub>1</sub> =137.6 |
| bush 2 | Pra <sub>2</sub> =393.3 | Pr <sub>2</sub> =341.1 | Prd <sub>2</sub> =288.9 |
|        | Psa <sub>2</sub> =187.3 | Ps <sub>2</sub> =162.4 | Psd <sub>2</sub> =137.6 |

◎ Equation for Dynamic Equivalent Load

$$P = Pr + Ps$$

$$Par = Pra<sub>1</sub> + Psa<sub>1</sub> = 393.3 + 187.3 = 580.6(N)$$

calculating in the same manner

Table 1-33

|        | acceleration           | constant              | deceleration           |
|--------|------------------------|-----------------------|------------------------|
| bush 1 | Pa <sub>1</sub> =580.6 | P <sub>1</sub> =503.5 | Pd <sub>1</sub> =426.5 |
| bush 2 | Pa <sub>2</sub> =580.6 | P <sub>2</sub> =503.5 | Pd <sub>2</sub> =426.5 |

◎ Calculating Average Equivalent Load

$$Pm = \sqrt{\frac{1}{\ell_s} \times \left( (Pa^3 \times \frac{V_{max} \times t_1}{2}) + (P^3 \times V_{max} \times t_2) + (Pd^3 \times \frac{V_{max} \times t_3}{2}) \right)}$$

$$Pm_1 = \sqrt{\frac{1}{120} \times \left( (580.6^3 \times \frac{150 \times 0.1}{2}) + (503.5^3 \times 150 \times 0.7) + (426.5^3 \times \frac{150 \times 0.1}{2}) \right)} = 505.0(N)$$

$$Pm_2 = \sqrt{\frac{1}{120} \times \left( (580.6^3 \times \frac{150 \times 0.1}{2}) + (503.5^3 \times 150 \times 0.7) + (426.5^3 \times \frac{150 \times 0.1}{2}) \right)} = 505.0(N)$$

### ④ Calculating Rated Life

Decide each coefficient

f<sub>H</sub>: hardness coefficient f<sub>H</sub>=1 for hardness of bush is 58HRC or more

f<sub>T</sub>: temperature coefficient f<sub>T</sub>=1 operating temperature is below 100°C  
(80°C is maximum for Bush with resin retainer)

f<sub>C</sub>: contact coefficient f<sub>C</sub>=1 for bushes are not in close contact

f<sub>w</sub>: applied load coefficient f<sub>w</sub>=1.5 for V<sub>max</sub>=150mm/s

◎ Calculating Rated Life

Selecting Bush 1 that carries the maximum equivalent load

$$L = \left( \frac{f_H \times f_T \times f_C}{f_w} \times \frac{C}{P_m} \right)^3 \times 50$$

$$L = \left( \frac{1 \times 1 \times 1}{1.5} \times \frac{2490}{505.0} \right)^3 \times 50 = 1775(\text{km})$$

◎ Calculating Life Time

$$L_h = \frac{L \times 10^3}{2 \times \ell_s \times n_1 \times 60}$$

$$L_h = \frac{1775 \times 10^3}{2 \times 0.120 \times 33 \times 60} = 3735(\text{hour})$$

### ⑤ Calculating Static Safety Factor

◎ Equation for Static Equivalent Load

$$Po = Pr + Ps$$

$$Po_1 = Pra_1 + Psa_1 = 393.3 + 187.3 = 580.6(N)$$

calculating in the same manner

Table 1-34

|        | acceleration           | constant               | deceleration           |
|--------|------------------------|------------------------|------------------------|
| bush 1 | Po <sub>1</sub> =580.6 | Po <sub>1</sub> =503.5 | Po <sub>1</sub> =426.5 |
| bush 2 | Po <sub>2</sub> =580.6 | Po <sub>2</sub> =503.5 | Po <sub>2</sub> =426.5 |

Selecting Bush 1 that carries the maximum static equivalent load

$$fs = \frac{Co}{Po}$$

$$fs = \frac{Co}{Po_1} = \frac{5490}{580.6} = 9.4$$

## RIGIDITY AND PRELOAD

### Effect of Preload and Rigidity

The rigidity of a linear system must be taken into consideration when it is to be used in high-precision positioning devices or high-precision machinery. Preloaded slide guides and ball splines, which use balls as the rolling elements, are available upon request to meet the need for greater rigidity.

If a force is applied to the ball elements without preload, an elastic deformation proportional to the applied force to the 2/3 power will result. Therefore, the elastic deformation is relatively large during the initial loading stage, however then becomes smaller as the load increases.


Preloading on the rolling elements absorbs the deformation of the block under the same loading.

Please contact NB for available data in regard to rigidity.

### Types of Preload and its Specification

Preload is categorized into three ranges: standard, light, and medium for option. In the NB linear system, preload is applied by installing rolling elements that are slightly larger than standard. Therefore, the specification of the preload is expressed by a negative value.

Figure 1-16 Applied Load versus Block Deformation



## FRICTIONAL RESISTANCE AND REQUIRED THRUST

The static friction of a linear system is extremely low. Since the difference between the static and dynamic friction is marginal, stable motion can be achieved from low to high speed. The frictional resistance (required thrust) can be obtained from the load and the seal resistance unique to each type of system using the following equation:

$$F = \mu \cdot W + f \quad \dots \dots \dots \quad (14)$$


F: frictional resistance (N)     $\mu$ : dynamic friction coefficient  
W: applied load (N)    f: seal resistance (N)

The dynamic friction coefficient varies with the applied load, preload, viscosity of the lubricant, and other factors. However, the values given in Table 1-35 are used for the normal loading condition (20% of basic dynamic load rating) without any preload. The seal resistance depends on the seal-lip condition as well as on the condition of the lubricant, however, it does not change proportionally with the applied load, which commonly is expressed by a constant value of 2 to 5 N.

Table 1-35 Dynamic Friction Coefficient

| product            | type                                   | dynamic friction coefficient ( $\mu$ ) |
|--------------------|--|--|
| Slide Guide        | SGL・SGW                                | 0.002~0.003                            |
|                    | SEB                                    | 0.004~0.006                            |
|                    | SER                                    | 0.004~0.006                            |
| Ball Spline        | SSP                                    | 0.004~0.006                            |
| Rotary Ball Spline | SPR・SPB<br>SPBR                        | 0.004~0.006                            |
| Stroke Ball Spline | SPLFS                                  | 0.001~0.003                            |
| Slide Bush         | SM・KB<br>SW・GM<br>SMA・SME              | 0.002~0.003                            |
|                    | TK・TKA<br>TKE・TKD<br>TW・TWA<br>TWJ・TWD | 0.002~0.003                            |
|                    | Top Ball                               |  |
| Stroke Bush        | SR                                     | 0.0006~0.0012                          |
| Slide Rotary Bush  | SRE                                    | 0.002~0.003                            |
|                    | RK                                     | 0.002~0.003                            |
| Slide Way          | NV・SV・RV                               | 0.001~0.003                            |
| Slide Table        | NVT・NYT・SVT・SYT                        | 0.001~0.003                            |
| Miniature Slide    | SYBS                                   | 0.001~0.003                            |

Figure 1-17 Applied Load versus Dynamic Friction Coefficient



## OPERATING ENVIRONMENT

### Temperature Range

The NB linear systems are heat-treated in order to harden the surface. Therefore, if the temperature of the linear system exceeds 100°C, the hardness and load rating will be reduced (refer to page Eng-5, hardness coefficient). If resin is used in any one of the components, the system cannot be used in a high-temperature environment. The recommended operating temperature ranges for each type of linear system are listed in Table 1-36.

Table 1-36 Major Types and Recommended Temperature Range

| component material          | includes resin   | steel                   | stainless          | other  |
|-----------------------------|--|-------------------------|--------------------|--------|
| operating temperature range | -20°C~80°C   | -20°C~110°C             | -20°C~140°C*       |        |
| Slide Guide                 | SEB-A/SEBS-B<br>SGL/SGW  | SER                     | SEBS-BM<br>SERS    |        |
| Ball Spline                 | SSP/SSPF/SPBF  |                         | SPLFS              |        |
| Rotary Ball Spline          | SPR/SPB/SPBR   |                         |                    |        |
| Slide Bush                  | SM G/KB G/<br>SW G/SMS G/<br>KBS G/SWS G/GM<br>SMA G/SMSA-W/<br>AK G/RBW/CE/CD | SM/KB/SW<br>SMA/AK/SMSA | SMS/KBS/SWS<br>AKS |        |
| Top Ball                    | TK/TKA<br>TKE/TKD<br>TW/TWA<br>TWJ/TWD   |                         |                    |        |
| Stroke Bush                 |  | SR/SRB                  |                    |        |
| Slide Rotary Bush           | RK   | SRE                     |                    |        |
| Slide Way                   | NV/NVS   | SV/RV                   | SVS/NVS-RNS        |        |
| Slide Table                 | NVT/NYT  | SVT/SYT                 | SYTS               | SVTS** |
| Miniature Slide             |  |                         | SYBS               |        |
| Slide Screw                 |  | SS                      |                    |        |

\* If the system is made of stainless steel and has a seal, the temperature range is up to 120°C

\*\* Please contact NB if the system is to be used out of room temperatures.


Temperature Conversion Equation:

$$C = \frac{5}{9}(F - 32) \quad F = \frac{9}{5}C + 32$$

### Operating Environment

Foreign particles or dust in the linear system affects the motion accuracy and shortens the life time. Standard seals will perform well for dust prevention under normal operating conditions, however, in a harsh environment it is necessary to attach bellows or protective covers as Figure 1-18 shows.

Figure 1-18 Example of Dust Prevention



## LUBRICATION

The objective of lubrication includes the reduction of friction among the rolling elements as well as between the rolling elements and the raceway, prevention of sintering, reduction of wear, and the prevention of rust by forming a film over the surfaces. To maximize the performance of a linear system, the lubricant type and a lubrication method appropriate for the operating environment should be selected.

There are two types of lubrication; oil lubrication and grease lubrication. For oil lubrication, turbine oil conforming to ISO standard VG32 to 68 is recommended.

For grease lubrication, lithium soap based grease No.2 is recommended. For slide bush and some other products, anti-rust oil that does not adversely affect the lubricant is applied prior to shipment. Please apply lubricant before using these products. (see Table 1-37) Products with raceway grooves, such as slide guide, are delivered pre-lubricated with grease for immediate use. Please relubricate with a similar type of grease periodically depending on the operating conditions. The recommended relubrication period is about 6 months or 1,000km of travel distance under normal conditions.

Table 1-37 Grease and Anti-rust oil

| type               | grease application |
|--------------------|--------------------|
| Slide Guide        | grease pre-applied |
| Ball Spline        | grease pre-applied |
| Rotary Ball Spline | grease pre-applied |
| Slide Bush         | anti-rust oil only |
| Stroke Bush        | anti-rust oil only |
| Slide Rotary Bush  | anti-rust oil only |
| Slide Way          | grease pre-applied |
| Slide Table        | grease pre-applied |
| Miniature Slide    | grease pre-applied |

NB provides the following optional greases. Please select one in accordance with the use conditions of your linear system.

### ●KGLA Grease (Low Dust Generation Grease)

KGLA Grease has an excellent property of low dust generation with a lithium-type thickening agent used. It is ideal for use in a clean room.

### ●KGU Grease (Low Dust Generation Grease)

With urea-type thickening agent used, KGU Grease has features including a superior low dust generation property and the reduced dynamic frictional resistance during low-speed operation.

Table 1-38 Main Property

| item   | grease name                         |                                     |
|--|-------------------------------------|-------------------------------------|
|  | KGLA Grease                         | KGU Grease                          |
| appearance   | whitish-yellow                      | light brown                         |
| base oil   | synthetic oil and refined oil mixed | synthetic oil and refined oil mixed |
| kinematic viscosity of base oil (mm <sup>2</sup> /s, 40°C) | 25                                  | 100                                 |
| thickening agent   | lithium soap                        | urea                                |
| mixture viscosity  | 260                                 | 248                                 |
| drop point (°C)  | 195                                 | 280 or higher                       |
| copper plate corrosion (100°C, 24hrs)                      | passed                              | passed                              |
| evaporation (mass%)  | 0.3 (99°C 22h)                      | 0.09 (99°C 22h)                     |
| oil separation (mass%100°C, 24hrs)                         | 4.6                                 | 0.5                                 |
| oxidation stability (MPa99°C, 100hrs)                      | 0.025                               | 0.015                               |
| bearing corrosion prevention (52°C, 48hrs)                 | passed                              | passed                              |
| operating temperature range (°C)                           | -40~120                             | -30~160                             |

Figure 1-19 Dust Level Measurement Data





Figure 1-20 Dynamic Frictional Resistance Measurement Data



### ●KGF Grease (Anti-fretting/Anti-corrosion Grease)

With urea-type thickening agent used, KGF Grease is very effective to prevent fretting and corrosion.

Table 1-39 Main Property


| item   | grease name     |
|--|-----------------|
| appearance   | KGF Grease      |
| base oil   | brown           |
| kinematic viscosity of base oil (mm <sup>2</sup> /s, 40°C) | synthetic oil   |
| thickening agent   | approx. 25      |
| mixture viscosity  | urea            |
| drop point (°C)  | 292             |
| copper plate corrosion (100°C, 24 hrs)                     | 250 or higher   |
| evaporation (mass%)  | passed          |
| oil separation (mass% 100°C, 24 hrs)                       | 0.27 (99°C 22h) |
| oxidation stability (MPa99°C, 100 hrs)                     | 1.1             |
| bearing corrosion prevention (52°C, 48 hrs)                | 0.085           |
| rinsing water resistance (38°C, 1 hr)                      | passed          |
| operating temperature range (°C)                           | 1.7             |
|  | -20~150         |

### Anti-fretting/Anti-corrosion Test Data

Table 1-40 Test Conditions

| item                    | content           |
|-------------------------|-------------------|
| tested item             | NVT4165           |
| stroke                  | 2 mm              |
| acceleration            | 2.4G              |
| average acceleration    | 0.1 m/s           |
| cycle per minute        | 1,450 cpm         |
| grease injection volume | 0.5 cc            |
| total travel distance   | 184 km            |
| total cycles            | 46 million cycles |

Figure 1-21 Raceway Condition after Testing



### ●Grease for the food processing industry (NSF H1 certified) is available.


It is the most suitable combination for the food processing applications to use this type of grease with stainless steel products. Please contact NB for details.

## NB MAINTENANCE KIT

There are two types of maintenance kit available at NB.

### 1. Grease Gun Set: GG1


Different types of nozzles are adaptable to a variety of products including Actuators and products with grease-fitting.



In the case of difficulty in pumping, due to internal grease adhesion or shape of the bearing, please use nozzle ④ to apply grease directly onto running grooves.

### 2. Grease Dispenser: TU1

Syringe dispenser is recommended for miniature guide (SEBS-B type) and for limited space applications.



## PRECAUTIONS FOR HANDLING AND USE

Please follow the instructions below to maintain the accuracy of NB linear system as a precision part and for a safety use.

#### (1) Notes on Handling

- ① Any shock load caused by rough handling (such as dropping or hitting with hammer) may cause a scar or dent on the raceway which will hinder smooth movement and shorten expected travel life. Also be aware that such impact may damage the resin parts.
- ② Never try to disassemble the product. Doing so may cause an entry of contamination or deterioration of assembly accuracy.
- ③ The blocks or the outer cylinders may move just by tilting the rail or the shaft. Be careful not to let them fall off from the rail or the shaft by mistake.
- ④ The accuracy on the mounting surface and parallelism of the rails or the shafts after assembly are important factors to optimize the performance of the linear system. Exercise adequate care for mounting accuracy.

#### (2) Notes on Use

- ① Be careful not to let dust or foreign particles enter the linear system during use.
- ② When using the linear system under an environment where dust or coolant may scatter, protect the system with a cover or bellows.

③ When the NB linear system is used in a manner that its rail is fixed to the ceiling and downward load is applied to the block(s) or the outer cylinder(s), if the block or the outer cylinder breaks, it may fall off from the rail and drop to the floor. Provide additional measures for preventing dropping of the block or the outer cylinder, such as a safety catch.

#### (3) Instructions in considering the "Life Time" of a Linear System

① When the load applied to a block or an outer cylinder exceeds 0.5 time of the basic dynamic load rating ( $P > 0.5C$ ), the actual life of the system may become shorter than a calculated life time. Therefore, it is recommended to use the system with 0.5C or lower.

② In the repetition of very minute stroke, where the rolling element, a steel ball or a cylindrical roller, makes only less than a half turn, early wear called fretting occurs at the contact points between the rolling elements and the raceway. There is no perfect measure to avoid this, but the life of the system can be extended by using anti-fretting grease and moving the blocks or the outer cylinders for the full stroke length once in a few thousand times of use.

Anti-fretting grease is available as an option. Please select it for applications with very minute stroke length.

# SLIDE GUIDE

## SLIDE GUIDE

|                                 |       |
|---------------------------------|-------|
| <b>STRUCTURE AND ADVANTAGES</b> | A-50  |
| <b>BLOCK TYPES</b>              | A-51  |
| <b>ACCURACY</b>                 | A-51  |
| <b>PRELOAD</b>                  | A-52  |
| <b>RAIL LENGTH</b>              | A-52  |
| <b>MOUNTING</b>                 | A-52  |
| <b>GREASE FITTING</b>           | A-53  |
| <b>LUBRICATION</b>              | A-53  |
| <b>DIMENSION TABLE</b>          | A-54~ |
| <b>STRUCTURE AND ADVANTAGES</b> | A-72  |
| <b>BLOCK TYPES</b>              | A-73  |
| <b>ACCURACY</b>                 | A-73  |
| <b>PRELOAD</b>                  | A-74  |
| <b>RAIL LENGTH</b>              | A-75  |
| <b>MOUNTING</b>                 | A-75  |
| <b>GREASE FITTING</b>           | A-75  |
| <b>DIMENSION TABLE</b>          | A-76~ |
| <b>STRUCTURE AND ADVANTAGES</b> | A-42  |
| <b>TYPES</b>                    | A-43  |
| <b>ACCURACY</b>                 | A-43  |
| <b>PRELOAD</b>                  | A-44  |
| <b>RAIL LENGTH</b>              | A-44  |
| <b>MOUNTING</b>                 | A-44  |
| <b>MOUNTING SCREW</b>           | A-45  |
| <b>LUBRICATION</b>              | A-45  |
| <b>DIMENSION TABLE</b>          | A-46~ |